

6705 Odyssey Drive Suite C Huntsville, AL 35806 Phone (256)713-1111 Fax (256)713-1112

Test Report for EAC 2005 VVSG Certification Testing Dominion Voting Systems Democracy Suite (D-Suite) Version 5.5-C Voting System

EAC Project Number: DVS-DemSuite5.5-C Version: Rev. 02 Date: 07/7/2020



EAC Lab Code 1501

NVLAP LAB CODE 200908-0

SIGNATURES

Approved by:

Michael L. Walker

Michael Walker, VSTL Project Manager

07/07/2020

Date

Approved by:

Wendy Owens Wendy Owens, VSTL Program Manager

07/07/2020

Date

REVISIONS

Revision	Description	Date
00	Initial Release	06/08/2020
01	Updated with EAC Comments, corrected typo in footer.	06/16/2020
02	Corrected typos	07/07/2020

TABLE OF CONTENTS

1.0	INTR	ODUCTION	1
1.1	Descri	ption and Overview of EAC System Being Modified	1
1.2	Refere	nces	14
1.3	Terms	and Abbreviations	14
2.0	CERT	IFICATION TEST BACKGROUND	15
2.1	Revisi	on History	15
2.2	Scope	of Testing	16
	2.2.1	Modification Overview	17
		2.2.1.1 Detailed List of Changes	17
		2.2.1.2 ECO Assessment	17
	2.2.2	Block Diagram	19
	2.2.3	System Limits	20
	2.2.4	Supported Languages	21
	2.2.5	Supported Functionality	22
	2.2.6	VVSG	22
	2.2.7	RFIs	22
	2.2.8	NOCs	23
3.0	TEST	FINDINGS AND RECOMMENDATION	23
3.1	Summ	ary Findings and Recommendation	23
	3.1.1	Physical Configuration Audit (PCA)	23
	3.1.2	TDP Review	24
	3.1.3	QA & CM System Review	30
	3.1.4	Source Code Review, Compliance Build, Trusted build, and Build Documentation	
		Review	
	3.1.5	Security Testing	
	3.1.6	System Level Testing	31
		3.1.6.1 Functional Configuration Audit (FCA)	32
		3.1.6.2 Volume & Stress	33
		3.1.6.3 Accuracy	34
		3.1.6.4 System Integration	34
	3.1.7	Usability and Accessibility Testing	35
	3.1.8	Hardware Testing	36

TR-01-01-DVS-38-01.02

4.0	RECOMMENDATION FOR CERTIFICATION	. 39
3.3	Deficiencies and Resolutions	. 39
3.2	Anomalies and Resolutions	. 39

ATTACHMENT A	HARDWARE TEST REPORTS	
--------------	-----------------------	--

1.0 INTRODUCTION

The purpose of this Test Report is to document the procedures that Pro V&V, Inc. followed to perform certification testing during a system modification campaign for the Dominion Voting Systems Democracy Suite (D-Suite) 5.5-C Voting System to the requirements set forth for voting systems in the U.S. Election Assistance Commission (EAC) 2005 Voluntary Voting System Guidelines (VVSG), Version 1.0. Certification testing of D-Suite 5.5-C was performed to ensure the applicable requirements of the EAC VVSG 1.0 and the EAC Testing and Certification Program Manual, Version 2.0 were met. Additionally, all EAC Request for Interpretations (RFI) and Notices of Clarification (NOC) relevant to the system under test were incorporated in the test campaign.

Prior to submitting the voting system for testing, Dominion Voting Systems submitted an application package to the EAC for certification of the D-Suite 5.5-C Voting System. The application was accepted by the EAC and the project was assigned the unique Project Number of DVS-DemSuite5.5-C.

The D-Suite 5.5-C EAC-approved test plan, which is available for viewing on the EAC's website at <u>www.eac.gov</u>, was utilized as the guiding document during test performance. Since test plan approval, and as testing progressed, minor system modifications, such as revised system documentation, were incorporated. This test report reflects all of the testing completed and details the final versions of all technical documentation and system components and supersedes the approved test plan.

Unless otherwise annotated, all testing was conducted at the Pro V&V test facility located in Huntsville, AL, by personnel verified by Pro V&V to be qualified to perform the test.

1.1 Description and Overview of EAC Certified System Being Modified

The EAC Certified System that is the baseline for the submitted modification is described in the following subsections. All information presented was derived from the previous Certification Test Report, the EAC Certificate of Conformance and/or the System Overview.

The D-Suite 5.5-C Voting System is a paper-based optical scan voting system. The D-Suite 5.5-C consists of the following major components: The Election Management System (EMS), the ImageCast Central (ICC), the ImageCast Precinct (ICP and ICP2), the ImageCast X (ICX) DRE w/ Reports Printer, ImageCast X (ICX) DRE w/VVPAT, the ImageCast Evolution (ICE), and the ImageCast X (ICX) BMD. The D-Suite 5.5-C Voting System configuration is a modification from the EAC approved D-Suite 5.5-B system configuration.

Detailed descriptions of the D-Suite 5.5-B test campaign are contained in Pro V&V Report No.TR-01-01-DVS-2019-01.02 Rev. 02, which is available for viewing on the EAC's website at <u>www.eac.gov</u>.

The following subsections describe the baselined D-Suite 5.5-B Voting System.

Election Management System (EMS)

The D-Suite 5.5-B EMS consists of various components running as either a front-end/client application or as a back-end/server application. A listing of the applications and a brief description of each is presented below.

Front-end/Client applications:

- <u>EMS Adjudication:</u> Represents the client component responsible for adjudication, including reporting and generation of adjudicated result files from ImageCast Central tabulators and adjudication of write-in selections from ImageCast Precinct and ImageCast Central tabulators. This client component is installed on both the server and the client machines.
- <u>EMS Audio Studio</u>: A client application that represents an end-user helper application used to record audio files for a given election project. As such, it is utilized during the pre-voting phase of the election cycle.
- <u>EMS Election Data Translator</u>: End-user application used to export election data from election project and import election data into election project.
- <u>EMS Election Event Designer:</u> A client application that integrates election definition functionality together with ballot styling capabilities and represents a main pre-voting phase end-user application
- <u>ImageCast Voter Activation</u>: An application, installed on a workstation or laptop at the polling place, which allows the poll workers to program smart cards for voters. The smart cards are used to activate voting sessions on ImageCast X.
- <u>EMS Results Tally and Reporting</u>: A client application that integrates election results acquisition, validation, tabulation, reporting, and publishing capabilities and represents the main post-voting phase end-user application.

Back-end/Server applications:

- <u>EMS Adjudication Service:</u> Represents a server side application which provides ballot information such as contests, candidates and their coordinates from EMS to the Adjudication application.
- <u>EMS Application Server:</u> Represents a server side application responsible for executing long running processes, such as rendering ballots, generating audio files and election files, etc.
- <u>EMS Database Server:</u> Represents a server side RDBMS repository of the election project database which holds all the election project data, including pre-voting and post-voting data.

- <u>EMS Data Center Manager</u>: A server application that represents a system level configuration application used in EMS back-end data center configuration.
- <u>EMS File System Service:</u> A back-end application that acts as a stand-alone service that runs on client machines, enabling access to low level operating system API for partitioning CF cards, reading raw partition on ICP CF card, etc.
- <u>EMS NAS Server</u>: Represents a server side file repository of the election project file based artifacts, such as ballots, audio files, reports, log files, election files, etc.
- <u>Smart Card Helper Service</u>: A service that is installed on a workstation or laptop at the polling place, and provides required data format for programming smart cards for ImageCast devices, or, for jurisdiction's voting registration system in case of integration.

ImageCast Precinct (ICP)

The ImageCast Precinct (ICP) device is a precinct optical scan ballot counter designed to provide three major functionalities: ballot scanning and tabulation, accessible voting, and ballot review and second chance voting. The ICP is used in conjunction with ImageCast compatible ballot storage boxes. The system is designed to scan marked paper ballots printed on standard or secure paper stock, interpret voter marks on the paper ballot, and safely store and tabulate each vote from each paper ballot. The ICP also supports enhanced accessibility voting through optional accessories connected to the ImageCast unit.

ImageCast Precinct (ICP2)

The ImageCast Precinct (ICP2) device is a precinct-based optical scan ballot counter designed to provide two major functionalities: ballot scanning and tabulation and ballot review and second chance voting. The ICP2 is used in conjunction with ImageCast compatible ballot storage boxes. The system is designed to scan marked paper ballots printed on standard or secure paper stock, interpret voter marks on the paper ballot, and safely store and tabulate each vote from each paper ballot.

ImageCast Evolution (ICE)

The ICE device is a precinct-level optical scan ballot counter designed to perform three major functions: ballot scanning and tabulation, ballot review and second chance voting, and accessible voting and ballot marking.

ImageCast Central (ICC) Count Scanner

The ImageCast Central (ICC) is a high-speed, central ballot optical scan tabulator based on Commercial off the Shelf (COTS) hardware, coupled with the custom-made ballot processing application software. It is used for high speed scanning and counting of paper ballots.

ImageCast X (ICX)

The Democracy Suite ImageCast X (ICX) consists exclusively of COTS available hardware and operating system, while the applications installed on top customize its behavior to turn it into a Ballot Marking Device (BMD) or a Direct-Recording Electronic (DRE) device with or without a Voter Verifiable Paper Audit Trail (VVPAT). ICX application is the application that verifies voter's session eligibility, using the smart card and then presents the appropriate ballot to the voter. When a voter is satisfied with choices selected, ICX application verifies them and produces an Electronic Mobile Ballot or stores the votes onto a memory device. The ICX is designed to perform the following functions:

- Ballot marking and printing of electronic mobile ballots (in BMD mode)
- Ballot review and second chance voting
- Accessible voting and ballot marking
- Saving voting results (in DRE mode)
- Printing votes on a voter verifiable paper audit trail device (when VVPAT is in use)

1.1.1 Baseline Certified System

This subsection lists the proprietary and COTS software provided by the manufacturer as part of the test campaign.

The baseline system for this modification is the D-Suite 5.5-B Voting System. The tables below describe the certified equipment and firmware versions. Detailed descriptions of the D-Suite 5.5-B test campaign are contained in Pro V&V Report No. TR-01-01-DVS-2019-01.02 Rev. 02, which is available for viewing on the EAC's website at www.eac.gov.

The tables below describe the certified equipment and firmware versions.

Software	Version	Filename	Configuration	
Software	version	Filename	Standard	Express
EMS Election Event Designer (EED)	5.5.32.4	setup.exe: EED_FED_CERT_Setup_x64.msi	Х	Х
EMS Results Tally and Reporting (RTR)	5.5.32.4	setup.exe: RTR_FED_CERT_Setup_x64.msi	Х	Х
EMS Application Server	5.5.32.4	setup.exe: APPS_FED_CERT_Setup_x64.msi	Х	Х
EMS File System Service (FSS)	5.5.32.4	setup.exe: FSSSetup.msi	Х	Х
EMS Audio Studio (AS)	5.5.32.4	setup.exe: EMSAudioStudioSetup.msi	Х	Х
EMS Data Center Manager (DCM)	5.5.32.4	DemocracySuiteEMS_DCM.exe	Х	Х

Software	Version	Filename	Configuration	
Software	version	Fliename	Standard	Express
EMS Election Data Translator (EDT)	5.5.32.4	setup.exe: EDTSetup_x86.msi, EDTSetup_x64.msi	Х	Х
ImageCast Voter Activation (ICVA)	5.5.32.4	setup.exe: ICVASetup.msi	X	Х
EMS Adjudication (Adj.)	5.5.32.1	DVS ImageCast Adjudication Client Setup.msi	X	Х
EMS Adjudication Service	5.5.32.1	DVS Adjudication Services Setup.msi	X	Х
Smart Card Helper Service	5.5.32.4	setup.exe: SmartCardServiceSetup.msi	Х	Х

 Table 1-1. Democracy Suite 5.5-B EMS Software Component Descriptions (continued)

Firmware/Software	Version	Filename
Election Firmware	5.5.31.1	cf2xx.sig
Firmware Updater	5.5.31.1	firmUp.enc
Firmware Extractor	5.5.31.1	FirmwareExtract.enc
Kernel (uClinux)	5.5.31.1	image.bin.gz
Boot Loader (COLILO)	20040221	colilo.bin
Asymmetric Key Generator	5.5.31.1	Keygen.enc
Asymmetric Key Exchange Utility	5.5.31.1	KeyExchange.enc
Firmware Extractor (Uses Technician Key)	5.5.31.1	TechExtract.enc

Table 1-3. Democracy Suite 5.5-B ImageCast Central Software Component Descriptions

Firmware/Software	Version	Filename
ImageCast Central Application	5.5.32.5	ICCSetup.exe

Table 1-4. Democracy Suite 5.5-B ImageCast X Software Component Descriptions

Firmware/Software	Version	Filename
ICX Application	5.5.13.2	ICX.apk

Table 1-5. Democracy Suite 5.5-B ImageCast Precinct 2 Software Component Descriptions

Firmware/Software	Version	Filename
ICP2 Application	5.5.1.8	dvs-release-image-icp2-5.5.1.8.vhd.7z
ICP2 Application (for units with 2 GB RAM)	5.5.1.8	dvs-release-image-icp2-2G-5.5.1.8.vhd.7z

Table 1-5. Democracy Suite 5.5-B ImageCast Precinct 2 Software Component Descriptions (continued)

Firmware/Software	Version	Filename
ICP2 Update Card	5.5.1.8	icp2-update-5.5.1.8

Table 1-6. Democracy Suite 5.5-B ImageCast Evolution Software Component Descriptions

Firmware/Software	Version	Filename
Voting Machine	5.5.6.5	GApplication-5.5.6.5.vhd.7z
Election Application	5.5.6.5	dvs
Linux Kernel	2.6.30.9-dvs-36	uImage
Linux Device File	1.6	mpc8347dvs.dtb
Root File System	5.0.31	rfs
Ram Disk	1.0.2	initrd.img
Motherboard FPGA	1.1.5	ice2_mc_p1.bit
Scanner Board FPGA	1.1.2	ice2_scb_p2.bit
Logger Controller	2.0.2	logger.bin
Power Controller	3.0.5	power.bin
Boot Loader	1.3.4.63	u-boot.bin
Integrated Printer	4.1.6	integratedPrinter.hex, printerFont.hex
Boot Startup Logo	6.0.0	logo_platform.bmp
Linux Startup Logo	6.0.0	logo_os.bmp
Application Startup Logo	6.0.0	application_startup_logo.bmp
Application Verification Logo	6.0.0	logo_application_verification.bmp
Ram Disk Verification Logo	6.0.0	logo_ramdisk_verification.bmp
Linux Tree Verification Logo	6.0.0	logo_os_tree_verification.bmp
Linux Verification Logo	6.0.0	logo_os_verification.bmp
RFS Verification Logo	6.0.0	logo_rfs_verification.bmp

Table 1-7. Democracy Suite 5.5-B EMS Client/Server Software Component Descriptions

Firmword/Software	Version	Filename	Configuration	
Firmware/Software	version	rnename	Standard	Express
Microsoft Windows Server	2012 R2 Standard	Physical Media from Microsoft	Х	
Microsoft Windows	10 Professional	Physical Media from Microsoft	Х	Х

Firmware/Software	Version	Filename	Configuration	
rifiliware/Soltware	version	Filename	Standard	Express
.NET Framework	3.5	Physical Media from Microsoft	Х	Х
Microsoft Visual J#	2.0	vjredist64.exe vjredist.exe	Х	Х
Microsoft Visual C++ 2013 Redistributable	2013	vcredist_x64.exe vcredist_x86.exe	Х	Х
Microsoft Visual C++ 2015 Redistributable	2015	vc_redist.x64.exe vc_redist.x86.exe	Х	Х
Java Runtime Environment	7u80	jre-7u80-windows-x64.exe jre-7u80-windows-i586.exe	Х	Х
Java Runtime Environment	8u144	jre-8u144-windows-x64.exe jre-8u144-windows-i586.exe	Х	Х
Microsoft SQL Server 2016 Standard	2016 Standard	Physical Media from Microsoft	Х	
Microsoft SQL Server 2016 Service Pack 1	2016 SP1	SQLServer2016SP1- KB3182545-x64-ENU.exe	Х	
Microsoft SQL Server 2016 SP1 Express	2016 SP1	SQLEXPRADV_x64_ENU.exe		Х
Cepstral Voices	6.2.3.801	Allison (English): Cepstral_Allison_windows_6.2. 3.801.exe Alejandra (Spanish): Cepstral_Alejandra_windows_6 .2.3.801.exe	Х	Х
Arial Narrow Fonts	2.37a	ARIALN.TTF ARIALNB.TTF ARIALNBI.TTF ARIALNI.TTF	Х	Х
Maxim iButton Driver	4.05	install_1_wire_drivers_x86_v4 05.msi install_1_wire_drivers_x64_v4 05.msi	Х	Х
Adobe Reader DC	AcrobatDC	AcroRdrDC1501020060_en_U S.exe	Х	Х
Microsoft Access Database Engine	2010	AccessDatabaseEngine.exe AccessDatabaseEngine_x64.ex e	Х	Х
Open XML SDK 2.0 for Microsoft Office	2.0	OpenXMLSDKv2.msi	Х	Х

 Table 1-7. Democracy Suite 5.5-B EMS Client/Server Software Component Descriptions

 (continued)

Firmware/Software	Version	Filename
Infragistics NetAdvantage	2011	NetAdvantage_WinForms_20111.msi
Win Forms 2011.1	Vol.1	
Infragistics NetAdvantage	2012	NetAdvantage_WPF_20121.msi
WPF 2012.1	Vol.1	<u> </u>
TX Text Control Library for .NET	16.0	TXText Control.NET for Windows Forms 16.0.exe
SOX	14.3.1	sox.exe, libgomp-1.dll, pthreadgc2.dll, zlib1.dll
NLog	1.0.0.505	NLog.dll
iTextSharp	5.0.5	itextsharp.dll
OpenSSL	1.0.2k & 2.0.14 FIPS	openssl.exe, libeay32.dll, ssleay32.dll
SQLite	1.0.103.0	System.Data.SQLite.DLL (32-bit and 64-bit)
Lame	3.99.4	lame.exe
Speex	1.0.4	speexdec.exe and speexenc.exe
Ghostscript	9.04	gsdll32.dll (32-bit and 64-bit)
One Wire API for .NET	4.0.2.0	OneWireAPI.NET.dll
Avalon-framework-cvs- 20020806	20020806	avalon-framework-cvs-20020806.jar
Batik	0.20-5	batik.jar
Fop	0.20-5	fop.jar
Microsoft Visual J# 2.0 Redistributable Package- Second Edition(x64)	2.0	vjc.dll , vjsjbc.dll, vjslibcw.dll, vjsnativ.dll , vjssupuilib.dll , vjsvwaux.dll
Entity framework	6.1.3	EntityFramework.dll
Spreadsheetlight	3.4.3	SpreadsheetLight.dll, SpreadsheetLight.xml
Open XML SDK 2.0 For Microsoft Office	2.0.5022.0	DocumentFormat.OpenXml.dll, DocumentFormat.OpenXml.xml

Table 1-8. Democracy Suite 5.5-B EMS Software Platform Unmodified COTS Component Descriptions

Table 1-9. Democracy Suite 5.5-B ImageCast Precinct Unmodified COTS Component Descriptions

Firmware/Software	Version	Filename
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz
Zlib	1.2.3	Zlib-1.2.3.tar.gz

Firmware/Software	Version	Filename
acl	2.2.52	acl-2.2.52.src.tar.gz
attr	2.4.47	attr-2.4.47.src.tar.gz
avahi	0.6.32	avahi-0.6.32.tar.gz
bash	4.3.30	bash-4.3.30.tar.gz
bash-completion	2.4	bash-completion-2.4.tar.xz
busybox	1.24.1	busybox-1.24.1.tar.bz2
bzip2	1.0.6	bzip2-1.0.6.tar.gz
coreutils	8.25	coreutils-8.25.tar.xz
cryptodev-linux	1.8	cryptodev-linux-1.8.tar.gz
cups	2.1.4	cups-2.1.4-source.tar.gz
db	6.0.35	db-6.0.35.tar.gz
dbus	1.10.10	dbus-1.10.10.tar.gz
dbus-glib	0.106	dbus-glib-0.106.tar.gz
dbus-test	1.10.10	dbus-1.10.10.tar.gz
depmodwrapper-cross	1	morty.tar.gz
e2fsprogs	1.43	e2fsprogs.git.tar.gz
expat	2.2.0	expat-2.2.0.tar.bz2
fontconfig	2.12.1	fontconfig-2.12.1.tar.gz
freetype	2.6.5	freetype-2.6.5.tar.bz2
gawk	4.1.3	gawk-4.1.3.tar.gz
gcc-runtime	6.2.0	gcc-6.2.0.tar.bz2
gettext	0.19.8.1	gettext-0.19.8.1.tar.gz
glib-2.0	2.48.2	glib-2.48.2.tar.xz
glibc	2.24	git2_sourceware.org.git.glibc.git.tar.gz
glibc-initial	2.24	git2_sourceware.org.git.glibc.git.tar.gz
glibc-locale	2.24	git2_sourceware.org.git.glibc.git.tar.gz
gmp	6.1.1	gmp-6.1.1.tar.bz2
gnutls	3.5.3	gnutls-3.5.3.tar.xz
gobject-introspection	1.48.0	gobject-introspection-1.48.0.tar.xz
grep	2.25	grep-2.25.tar.xz

Table 1-10. Democracy Suite 5.5-B ImageCast Precinct 2 Unmodified COTS Component Descriptions

Firmware/Software	Version	Filename
icu	57.1	icu4c-57_1-src.tgz
imx-gpu-viv	6.2.2.p0-aarch32	imx-gpu-viv-6.2.2.p0-aarch32.bin
kbd	2.0.3	kbd-2.0.3.tar.xz
kernel-module-imx-gpu-viv	6.2.2.p0	kernel-module-imx-gpu-viv- 6.2.2.p0.tar.gz
kmod	23+gitAUTOINC +65a885df5f	git2_git.kernel.org.pub.scm.utils.kernel. kmod.kmod.git.tar.gz
libcap	2.25	libcap-2.25.tar.xz
libcgroup	0.41	libcgroup-0.41.tar.bz2
libcheck	0.10.0	check-0.10.0.tar.gz
libdaemon	0.14	libdaemon-0.14.tar.gz
libdrm	2.4.70	libdrm-2.4.70.tar.bz2
libevdev	1.5.2	libevdev-1.5.2.tar.xz
libffi	3.2.1	libffi-3.2.1.tar.gz
libgcc	6.2.0	libgcc-5-dev_5.4.0- 6ubuntu1~16.04.10_amd64.deb
libgcc-initial	6.2.0	libgcc-5-dev_5.4.0- 6ubuntu1~16.04.10_amd64.deb
libidn	1.33	libidn-1.33.tar.gz
libinput	1.8.4	libinput-1.8.4.tar.xz
libjpeg-turbo	1.5.0	libjpeg-turbo-1.5.0.tar.gz
libnss-mdns	0.1	nss-mdns-0.10.tar.gz
libpcap	1.7.4	libpcap-1.7.4.tar.gz
libpciaccess	0.13.4	libpciaccess-0.13.4.tar.bz2
libpcre	8.39	libpcre32-3_2%3a8.38-3.1_amd64.deb
libpng	1.6.24	libpng-1.6.24.tar.xz
libpthread-stubs	0.3	libpthread-stubs-0.3.tar.bz2
libtool-cross	2.4.6	libtool-2.4.6.tar.gz
libusb1	1.0.20	libusb-1.0.20.tar.bz2
libusb-compat	0.1.5	libusb-compat-0.1.5.tar.bz2
libxkbcommon	0.6.1	libxkbcommon-0.6.1.tar.xz
libxml2	2.9.4	libxml2-2.9.4.tar.gz
linux-libc-headers	4.9	linux-4.9.tar.xz

Table 1-10. Democracy Suite 5.5-B ImageCast Precinct 2 Unmodified COTS Component Descriptions (continued)

Firmware/Software	Version	Filename
log4cplus	1.2.0	log4cplus-1.2.0.tar.gz
m4	1.4.17	m4-1.4.17.tar.gz
mesa	12.0.1	mesa-12.0.1.tar.xz
mtdev	1.1.5	mtdev-1.1.5.tar.bz2
nettle	3.2	nettle-3.2.tar.gz
openssl	1.0.2k	openssl-1.0.2k.tar.gz
openssl-fips	2.0.10	openssl-fips-2.0.10.tar.gz
opkg-utils	0.3.2+gitAUTOI NC+3ffe ce9bf1	opkg-0.3.3.tar.gz
pkgconfig	0.29.1+gitAUTO INC+87152c05b e	git2_anongit.freedesktop.org.pkg- config.tar.gz
ppp	2.4.7	ppp-2.4.7.tar.gz
procps	3.3.12	procps-ng-3.3.12.tar.xz
qtbase	5.9.6+gitAUTOI NC+f4c2fcc052	qtbase- 5.9.6+gitAUTOINC+9c50112304.tar.gz
qtdeclarative	5.9.6+gitAUTOI NC+dfb e918537	qtdeclarative- 5.9.6+gitAUTOINC+283a900c4e.tar.gz
qtgraphicaleffects	5.9.6+gitAUTOIN C+3d317f1bb0	qtgraphicaleffects- 5.9.6+gitAUTOINC+f61dcaa5e5.tar.gz
qtquickcontrols2	5.9.6+gitAUTOI NC+c51 eea8870	qtquickcontrols2- 5.9.6+gitAUTOINC+c48b314ede.tar.gz
qtquickcontrols	5.9.6+gitAUTOI NC+f050a32a43	qtquickcontrols- 5.9.6+gitAUTOINC+ca6bba7163.tar.gz
qtsvg	5.9.6+gitAUTOI NC+dec74295e8	qtsvg- 5.9.6+gitAUTOINC+7a28db8f5b.tar.gz
qtxmlpatterns	5.9.6+gitAUTOI NC+c7c5681004	qtxmlpatterns- 5.9.6+gitAUTOINC+4dcae15a5a.tar.gz
quazip	0.7.3	quazip-0.7.3.tar.gz
readline	6.3	readline-6.3.tar.gz
run-postinsts	1	morty.tar.gz
sed	4.2.2	sed-4.2.2.tar.gz
shadow	4.2.1	shadow-4.2.1.tar.xz
shadow-securetty	4.2.1	shadow-4.2.1.tar.xz
sqlite3	3.14.1	sqlite-autoconf-3140100.tar.gz
systemd	230+gitAUTOIN C+3a74d4fc90	git2_github.com.systemd.systemd.git.ta r.gz
tcl	8.6.6	tcl8.6.6-src.tar.gz

 Table 1-10. Democracy Suite 5.5-B ImageCast Precinct 2 Unmodified COTS Component Descriptions (continued)

Firmware/Software	Version	Filename
tslib	1.1	tslib-1.1.tar.xz
tzdata	2017a	tzdata2017a.tar.gz
usb-modeswitch	2.2.0	usb-modeswitch-2.2.0.tar.bz2
usb-modeswitch- data	20140529	usb-modeswitch-data-20140529.tar.bz2
util-linux	2.28.1	util-linux-2.28.1.tar.xz
util-macros	1.19.0	util-macros-1.19.0.tar.gz
XZ	5.2.2	xz-5.2.2.tar.gz
zbar	0.1	zbar-0.10.tar.bz2
zlib	1.2.8	zlib-1.2.8.tar.xz
flac	1.3.1	flac-1.3.1.tar.xz
gst-plugins-base	1.10.4	gst-plugins-base-1.10.4.tar.xz
gst-plugins-good	1.10.4	gst-plugins-good-1.10.4.tar.xz
gstreamer	1.10.4	gstreamer-1.10.4.tar.xz
harfbuzz	1.3.0	harfbuzz-1.3.0.tar.bz2
libgudev	230	libgudev-230.tar.xz
libical	2.0.0	libical-2.0.0.tar.gz
libogg	1.3.2	libogg-1.3.2.tar.xz
libsamplerate	0.1.8	libsamplerate-0.1.8.tar.gz
libsndfile	1.0.27	libsndfile-1.0.27.tar.gz
libvorbis	1.3.5	libvorbis-1.3.5.tar.xz
speex	1.2rc2	speex-1.2rc2.tar.gz
speexdsp	1.2rc3	speexdsp-1.2rc3.tar.gz
taglib	1.9.1	taglib-1.9.1.tar.gz
qtmultimedia	5.9.6+gitAUTOI NC+52f5785cfa	qtmultimedia- 5.9.6+gitAUTOINC+52f5785cfa.tar.gz

 Table 1-10. Democracy Suite 5.5-B ImageCast Precinct 2 Unmodified COTS Component Descriptions (continued)

Table 1-11. Democracy Suite 5.5-B ImageCast Evolution Unmodified COTS Component Descriptions

Firmware/Software	Version	Filename
BusyBox	1.20.2	busybox-1.20.2.tar.bz2
e2fsprogs	1.42.4	e2fsprogs-1.42.4.tar.gz
Expat XML Parser	2.1.0	expat-2.1.0.tar.gz

Firmware/Software	Version	Filename
fontconfig	2.9.0	fontconfig-2.9.0.tar.gz
Freetype	2.4.9	freetype-2.4.9.tar.bz2
I2C Tools for Linux	3.1.0	i2c-tools-3.1.0.tar.bz2
JPEG library	8d	jpegsrc.v8d.tar.gz
libogg	1.3.0	libogg-1.3.0.tar.gz
libPNG	1.5.10	libpng-1.5.10.tar.gz
libusb	1.0.8	libusb-1.0.8.tar.bz2
libusb-compat	0.1.3	libusb-compat-0.1.3.tar.bz2
log4cplus	1.0.4.1	log4cplus-1.0.4.1.tar.bz2
openssl	1.0.2k	openssl-1.0.2k.tar.gz
openssl-fips	2.0.10	openssl-fips-2.0.10.tar.gz
PPP	2.4.5	ppp-2.4.5.tar.gz
quazip	0.5	quazip-0.5.tar.gz
Qt Everywhere Linux	4.7.3	qt-everywhere-opensource-src- 4.7.3.tar.gz
skell	1.19	skell-1.19.tar.gz
SoundTouch	1.6.0	soundtouch-1.6.0.tar.gz
speex	1.2rc1	speex-1.2rc1.tar.gz
SQLite	3.7.13	sqlite-autoconf-3071300.tar.gz
Sysfs Utilities	2.1.0	sysfsutils-2.1.0.tar.gz
TIFF library	4.0.1	tiff-4.0.1.tar.gz
timezone	2012b	tzcode2012b.tar.gz
USB ModeSwitch	1.2.4	usb-modeswitch-1.2.4.tar.bz2
zlib	1.2.7	zlib-1.2.7.tar.bz2

 Table 1-11. Democracy Suite 5.5-B ImageCast Evolution Unmodified COTS Component Descriptions (continued)

Table 1-12. Democracy Suite 5.5-B ImageCast X Unmodified COTS Component Descriptions

Firmware/Software	Version	Filename
		ARM: com.google.android.tts_3.11.12-
Google Text-to-Speech	3.11.12	210311121_minAPI19(armeabi-v7a)(nodpi).apk
Engine		x86: com.google.android.tts_3.11.12-
		210311123_minAPI15(x86)(nodpi).apk
ICX Prime Android	0405	0405_5.1.1-01.12_user_android_x86.iso
5.1.1 Image	0405	0+05_5.1.1-01.12_use1_android_x80.180

Table 1-12. Democracy Suite 5.5-B ImageCast X Unmodified COTS Component Descriptions (continued)

Firmware/Software	Version	Filename
ICX Classic Android 4.4.4 Image	0.0.98	byt_t_crv2_64-ota-BCX18-V0.0.98.zip

Table 1-13. Democracy Suite 5.5-B ImageCast Central Software Build Library Source Code (Unmodified COTS)

Firmware/Software	Version	Filename
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz

Table 1-14. Democracy Suite 5.5-B ImageCast Central Runtime Software Components (Unmodified COTS)

Firmware/Software	Version	Filename
1-Wire Driver (x86)	4.05	install_1_wire_drivers_x86_v405.msi
1-Wire Driver (x64)	4.05	install_1_wire_drivers_x64_v405.msi
Canon DR-G1130 TWAIN Driver	1.2 SP6	G1130_DRIT_V12SP6.exe
Canon DR-M160II TWAIN Driver	1.2 SP6	M160II_DRIT_V12SP6.exe
Visual C++ 2013 Redistributable (x86)	12.0.30501	vcredist_x86.exe
InoTec HiPro 821 TWAIN Driver	1.2.3.17	TwainSetup-ScamaxUSB3.exe
Canon DR-M260 TWAIN Driver	1.1 SP2	M260_DRIT_V11SP2.zip

Table 1-15. Democracy Suite 5.5-B ImageCast Precinct Modified COTS Software Component Descriptions

Firmware/Software	Version	Filename
uClinux	20070130	uClinux-dist-20070130.tar.gz
COLILO Bootloader	20040221	Colilo20040221.tar.gz

Table 1-16. Democracy Suite 5.5-B ImageCast Precinct 2 Modified COTS Software Component Descriptions

Firmware/Software	Version	Filename
Kernel	4.9.11	zImage
U-BOOT	2017.03	u-boot.bin

Table 1-17. Democracy Suite 5.5-B ImageCast Evolution Modified COTS Software Component Descriptions

Firmware/Software	Version	Filename
Kernel	2.6.30	uImage
U-BOOT	1.3.4	u-boot.bin

Table 1-18. Democracy Suite 5.5-B ImageCast X Modified COTS Software Component Descriptions

Firmware/Software	Version	Filename
Zxing Barcode Scanner	4.7.5	BS-4.7.5.zip
SoundTouch	1.9.2	Soundtouch-1.9.2.tar.gz

Table 1-19. Democracy Suite 5.5-B EMS Software Build Environment Component Descriptions

Firmware/Software	Version	Filename
Windows 10 Professional	10 Professional	Physical Media from Microsoft
.NET Framework 3.5	3.5	Physical Media from Microsoft
Internet Information Server (IIS)	10.0	Physical Media from Microsoft
7-Zip	9.20 (64 Bit)	7z920-x64.msi
Visual Studio 2015 Professional with Update 3	2015 Update 3	en_visual_studio_professional_2015_wi th_update_3_x86_x64_web_installer_8 922978.exe
.NetDiscUtils	0.10	DiscUtilsBin-0.10.zip
Infragistics NetAdvantage Win Forms 2011.1	2011.1	NetAdvantage_WinForms_20111.msi
Infragistics Net Advantage – WPF 2012.1	2012.1	NetAdvantage_WPF_20121.msi
TX Text Control 16.0.NET	16	TX Text Control.NET for Windows Forms 16.0.exe
Speex	1.0.4	speex_win32_1.0.4_setup.exe
Microsoft Visual J#	2.0	vjredist64.exe
iTextSharp	5.0.5	itextsharp-5.0.5-dll.zip
Ghostscript	9.0.4	gs904w32.exe, gs904w64.exe
Nlog	1.0.0.505	NLog-1.0-Refresh-bin.zip
OneWireAPI.NET	4.0	1-wiresdkver400_beta2.zip
Lame	3.99.4	lame3.99.4-20120130.zip
Sox	14.3.1	sox-14.3.1-win32.zip
Avalon Framework	20020806	avalon-framework-cvs-20020806.jar.zip

Firmware/Software	Version	Filename
Fop	0.20-5	fop-0.20.5.jar
Batik	0.20-5	batik-1.5-fop-0.20-5.jar
SQLite	1.0.103.0	sqlite-netFx46-setup-bundle-x64-2015- 1.0.103.0.exe
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz
Strawberry Perl	5.24.1.1	strawberry-perl-5.24.1.1-64bit.msi
Patch	2.5.9-7	patch-2.5.9-7-bin.zip
ISOnewspaper	30.4	ISOnewspaper30v4_gr.icc.zip
Ogg Vorbis Encoder	2.88	oggenc2.88-1.3.5-generic.zip
Ogg Vorbis Encoder	1.10.1	oggdecV1.10.1.zip
Prism Mvvm	1.1.1	prism.mvvm.1.1.1.nupkg
Bitmiracle.libtiff.net	2.4.560	Bitmiracle.libtiff.net.2.4.560.nupkg
Prism	4.0.0	prism.4.0.0.nupkg
Prism.UnityExtensions	4.0.0	prism.unityextensions.4.0.0.nupkg
PDF Printing	2.9.5.2	PDFPrinting.zip
Entity Framework	6.1.3.net45	entityframework.6.1.3.nupkg
WiX	3.10	Wix310.exe
Spreadsheet Light	3.4.3	spreadsheetlight.3.4.3.nupkg
Open XML SDK 2.0 for Microsoft Office	2.0	OpenXMLSDKv2.msi
Adobe Reader DC	AcrobatDC	AcroRdrDC1501020060_en_US.exe
Arial Narrow Fonts	2.37a	ArialNarrowFonts.zip
SSH.NET	2016.1.0	SSH.NET-2016.1.0-bin.zip
SSMS	14.0.17119.0	SSMS-Setup-ENU.exe
TwainDSM	2.3.0	Twaindsm-2.3.0.win.bin

 Table 1-19. Democracy Suite 5.5-B EMS Software Build Environment Component Descriptions (continued)

Table 1-20. Democracy Suite 5.5-B ICC Software Build Environment Component Descriptions

Firmware/Software	Version	Filename
NASM Assembler	2.12.02	nasm-2.12.02-win32.zip
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz

Firmware/Software	Version	Filename
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz
CSC3-2010	N/A	CSC3-2010.crl
tss-ca-g2	N/A	tss-ca-g2.crl

Table 1-20. Democracy Suite 5.5-B ICC Software Build Environment Component Descriptions (continued)

Table 1-21. Democracy Suite 5.5-B Adjudication Software Build Environment Component Descriptions

Firmware/Software	Version	Filename
Microsoft Enterprise Library	5.0	Enterprise Library 5.0.msi
Microsoft Prism	4.0.0	Prism.4.0.0.nupkg
Microsoft Identity Foundation SDK	4.0	WindowsIdentityFoundation-SDK- 4.0.msi
Toggle Switch Control Library	1.1.1	ToggleSwitch 1.1.1.zip
Infragistics NetAdvantage Ultimate 2013.1	2013.1	NetAdvantage_20131_PlatformInst aller.zip
iTextSharp	5.5.1	itextsharp-all-5.5.1.zip
CLR Security	June 2010	clrsecurity_june10.zip
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz
Community MSI Extensions	1.4	msiext-1.4.zip
TreeViewEx	3.0.0.0	TreeViewEx.dll

Table 1-22. Democracy Suite 5.5-B ImageCast Precinct Election Firmware Compiler Descriptions

Firmware/Software	Version	Filename
g++ (GNU C++ compiler)	gcc3.4.0-20040603	m68k-uclinux-tools-c++-gcc3.4.0- 20040603.sh

Table 1-23. Democracy Suite 5.5-B ImageCast Precinct Firmware Build Environment Component Descriptions

Firmware/Software	Version	Filename
Ubuntu 16.04.1	16.04.1	ubuntu-16.04.1-desktop-i386.iso
Toolchain Installation Script	N/A	Toolchain.sh
m68k uClinux tools base gcc	3.4.0-20040603	m68k-uclinux-tools-base-gcc3.4.0- 20040603.sh
m68k uClinux tools c++ gcc	3.4.0-20040603	m68k-uclinux-tools-c++-gcc3.4.0- 20040603.sh

Firmware/Software	Version	Filename
m68k uClinux tools gdb	20040603	m68k-uclinux-tools-gdb-20040603.sh
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz

Table 1-23. Democracy Suite 5.5-B ImageCast Precinct Firmware Build Environment Component Descriptions (continued)

Table 1-24. Democracy Suite 5.5-B ImageCast Precinct 2 Firmware Build Environment Component Descriptions

Firmware/Software	Version	Filename
Ubuntu	16.04 LTS	ubuntu-16.04.5-desktop-amd64.iso
Yocto	imx-morty	morty.tar.gz
asciidoc	8.6.9	asciidoc_8.6.9-3_all.deb
autoconf	2.69	autoconf_2.69-9_all.deb
automake	1.15	automake_1%3a1.15-4ubuntu1_all.deb
p7zip- full	9.20.1~dfsg.1	p7zip-full_9.20.1~dfsg.1-4.2_amd64.deb
avr-libc	1.8.0+Atmel3.5.0	avr-libc_1%3a1.8.0+Atmel3.5.0-1_all.deb
binutils-avr_	2.25+Atmel3.5.0	binutils-avr_2.25+Atmel3.5.0- 2_amd64.deb
python-dev	2.7.12	python-dev_2.7.12-1~16.04_amd64.deb
python3	3.5.1	python3-dev_3.5.1-3_amd64.deb
python3-pip	8.1.1	python3-pip_8.1.1-2ubuntu0.4_all.deb
python-pysqlite2	2.7.0	python-pysqlite2_2.7.0-1_amd64.deb
chrpath	0.16	chrpath_0.16-1_amd64.deb
socat	1.7.3.1	socat_1.7.3.1-1_amd64.deb
cvs	1.12.13	cvs_2%3a1.12.13+real- 15ubuntu0.1_amd64.deb
desktop-file-utils	0.22	desktop-file-utils_0.22- 1ubuntu5.2_amd64.deb
psutils	1.17.dfsg	psutils_1.17.dfsg-2_amd64.deb
docbook-utils	0.6.14	docbook-utils_0.6.14-3ubuntu1_all.deb
libsdl1.2-dev	1.2.15+dfsg1	libsdl1.2-dev_1.2.15+dfsg1-3_amd64.deb
help2man	1.47.3	help2man_1.47.3_amd64.deb
texi2html	1.82+dfsg1	texi2html_1.82+dfsg1-5_all.deb
libg11-mesa-dev	18.0.5	libgl1-mesa-dev_18.0.5- 0ubuntu0~16.04.1_amd64.deb

Firmware/Software	Version	Filename
libglu1-mesa-dev	9.0.0	libglu1-mesa-dev_9.0.0-2.1_amd64.deb
mercurial	3.7.3	mercurial_3.7.3-1ubuntu1_amd64.deb
g++-5	5.4.0	g++-5_5.4.0- 6ubuntu1~16.04.10_amd64.deb
gawk	4.1.3	gawk_1%3a4.1.3+dfsg-0.1_amd64.deb
lzop	1.03	lzop_1.03-3.2_amd64.deb
gcc	5.4.0	gcc-5_5.4.0- 6ubuntu1~16.04.10_amd64.deb
gcc-5-multilib	5.4.0	gcc-5-multilib_5.4.0- 6ubuntu1~16.04.10_amd64.deb
gcc-avr	4.9.2+Atmel3.5.3	gcc-avr_1%3a4.9.2+Atmel3.5.0- 1_amd64.deb
git	2.7.4	git_1%3a2.7.4-0ubuntu1.4_amd64.deb
zlib	1.2.8	zlib1g-dev_1%3a1.2.8.dfsg- 2ubuntu4.1_amd64.deb
texinfo	6.1.0.dfsg.1	texinfo_6.1.0.dfsg.1-5_amd64.deb
groff	1.22.3	groff_1.22.3-7_amd64.deb

Table 1-24. Democracy Suite 5.5-B ImageCast Precinct 2 Firmware Build Environment Component Descriptions (continued)

Table 1-25. Democracy Suite 5.5-B ImageCast Evolution Firmware Build Environment Component Descriptions

Firmware/Software	Version	Filename
Ubuntu	10.04 LTS	ubuntu-10.04.4-desktop-i386.iso
LTIB	10.1.1a	ltib-10-1-1a-sv.tar.gz
g++ (GNU C++ compiler)	gcc-4.5.38-	freescale-powerpc-linux-gnu-2011.03-
gri (Grio eri complici)	eglibc-2.11.38	38.i686.rpm
autoconf	2.57	autoconf-2.57.tar.bz2
bison	2.3	bison-2.3.tar.bz2
ccache	2.4	ccache-2.4.tar.gz
cksum	19990607	cksum-19990607.tar.gz
cramfs	20081121	cramfs-20081121.tar.gz
distcc	2.18.3	distcc-2.18.3.tar.bz2
dtc	1.2.0	dtc-1.2.0.tar.gz
flex	2.5.33	flex-2.5.33.tar.gz
genext2fs	1.4.1	genext2fs-1.4.1.tar.gz
gen_init_cpio	2.6.25-rc7	gen_init_cpio-2.6.25-rc7.tar.gz
genromfs	0.5.1	genromfs-0.5.1.tar.gz
git	1.5.6.5	git-1.5.6.5.tar.gz

Firmware/Software	Version	Filename
libtool	1.5	libtool-1.5.tar.gz
lkc	1.4	lkc-1.4.tar.gz
mkspooflinks	3.4	mkspooflinks-3.4.tar.gz
mtd-utils	20060302	mtd-utils-20060302.tar.bz2
mux_server	1.0	mux_server.c
pkg-config	0.21	pkg-config-0.21.tar.gz
sparse	0.4	sparse-0.4.tar.gz
texinfo	4.8	texinfo-4.8.tar.bz2
tunctl	1.5	tunctl-1.5.tar.gz
u-boot-tools	1.1.6	u-boot-tools-1.1.6.tar.bz2
unifdef	1.0	unifdef-1.0.tar.gz
wget	1.9.1	wget-1.9.1.tar.gz
yaffs_utils	20060418	yaffs_utils-20060418.tar.gz
rpm	4.0.4	rpm-4.0.4.tar.gz

Table 1-25. Democracy Suite 5.5-B ImageCast Evolution Firmware Build Environment Component Descriptions (continued)

Table 1-26. Democracy Suite 5.5-B ImageCast X Firmware Build Environment Component Descriptions

Firmware/Software	Version	Filename
Ubuntu 14.04.4	14.04.4	ubuntu-14.04.4-desktop-amd64.iso

Table 1-27. D-Suite 5.5-B Configuration Files

Configuration File	Version	Filename
ICX Machine Configuration File (MCF)	5.5.12.1_20190510	MCF_5.5.12.1_20190510.mcf
ICP/ICC Device Configuration File (DCF)	5.5.31_20190423	DCF_5.5.31_20190423.dcf
ICE Machine Behavior Settings	5.5.6.3 20190512	behaviorsettings_ICE_5.5.6.3_EAC_2 0190512.mbs
ICP2 Machine Behavior Settings	5.5.1.4 20190510	behaviorsettings_ICP2_5.5.1.4_EAC_ 20190510.mbs

Table 1-28. D-Suite 5.5-B Voting System Equipment

Component	Serial Number
Proprietary Hardware	
ImageCast Precinct Optical Scanner PCOS-320C	AAFAJFM0061, AAFAJFN0030, AAFAJGI6764, AAFAJEL0352
ImageCast Precinct Optical Scanner PCOS-320A	AANAGCP0347, AANAGCP0002

Component	Serial Number
ImageCast Precinct 2 Optical Scanner PCOS-330A	FAL18480494, FAL18480510
ImageCast Evolution Optical Scanner PCOS-410A	AAFEBIK1847, AAFEBCN0012
ICP Ballot Box BOX-330A	AAUCCFX0083, AAUCCGI0011
ICE Ballot Box	
ICX Inline EMI Filter	[DVS-EMIFILTER-001] thru [DVS-EMIFILTER-003]
ICP2 Ballot Box BOX-350A	
	COTS Hardware
ICX aValue 15" Tablet (SID- 15V)	0E14AF00014, B03G005400006, B033G00540008, 9E274118, 1D274118, Baytrail98D750C0, Baytrail12034DCC, Baytrail9A6550C8
ICX aValue 21" Tablet (SID- 21V)	0E14AF00027, B03G005500019, 03G005500009, 0039BZ2D, 0039B209, Baytrail0039B22D, BaytrailF1B2587F, BaytrailF1B25983
aValue 21" ICX DRE (Prime)	1707101522, 1707101789, 1707101730, 1707101887, 1707101710, 1707101725, 1707101731, 1708100916, 1708100876, 1708100915, 1707101845, 1707101778, 1717101720, 1707101845, 1707101722, 1707202552, 1711300282, 1707100089, 1707101795, 1707101793, 17101793
SII Thermal Printer	1115271A, 1115273A, 115270A, 1115275A
KFI VRP3 Thermal Printer (VVPAT)	KPR000000715, KPR0000078339, KPR0000078377, KRP000000711, KPR000000712, KPR170900010119, KPR0000078337, KPR0000078364, KPR170900008115, KPR0000078339, KPR17090008116, KPR170900010347, KPR170900009733, KPR170900010120, KPR170900010119, KPR170900010337, KPR170900010338, KPR170900010348
Dell OptiPlex 7440 All In One	HVNRFB2, HVNQFB2, HVNPFB2
Dell PowerEdge R630	4Z07T52
Dell PowerEdge R640	JMP9CM2
Canon imageFormula DR-G1130 Scanner	GF301092, GF304418
Canon DR-M160II Scanner	GX333569, GX333573, GX324846, GX326272, GX319353
Canon DR-M260 Scanner	HG306013, HG306012
InoTec HiPro 821 Scanner	0078K28, 0080K28
Dell Precision T3420 PC	HS0VFB2, HS0TFB2, HS0RFB2, HS0SFB2, 4TB3MN2, F575HH2
HP LaserJet Pro Printer M402dn	PHBQF20342, PHBQF20345, PHBQC12619, PHBQC19613, PHBQC12519, PHBQD18790, PHBQC12616, PHBQG09329

 Table 1-28. D-Suite 5.5-B Voting System Equipment (continued)

Component	Serial Number
HP LaserJet Pro Printer	PHB5D00782, PHB5D04714, PHB5F04770, PHB5B18304,
M402dne	PHB5D04713
Dell OptiPlex 9030 All-In-One	CF73852
Dell Ultrasharp 24" Monitor U2414H	1PVZ152, 62VZ152
Dell OptiPlex 3050 All-In-One	19YWWK2
Smart Card Reader ACR39	RR374-010362

 Table 1-28. D-Suite 5.5-B Voting System Equipment (continued)

Table 1-29. D-Suite 5.5-B Voting System Support Equipment

Component	Serial Number
Dell Monitor KM632	FYNTY12, CKX6Y12, CN-0524N3-72461-59H-6U5U
Dell Monitor P2414Hb	CN-0524N3-74261-5AH-2DNU, CN-0524N3-74261- 5AH-2DAU
Dell DVD Multi Recorder GP60NB60	[DVS-Dell-001]
Dell Latitude E7450 Laptop	30GFH72, 369FH72
Dell Latitude e3480 Laptop	1VD3NJ2
Maxim iButton Programmer DS9490R# with DS1402	[DVS-Maxim-001] thru [DVS-Maxim-006]
APC Smart-UPS SMT1500	3\$1536X06436, 3\$1536X06475, 3\$1536X06461, 3\$1536X06485, 3\$1536X06484, 3\$1536X06322, 3\$1536X07467, 3\$1536X06485, 3\$1536X06272, 3\$1536X06201, 3\$1536X07305, 3\$1504X00395, 3\$1504X00396, 351716X02289, W51530180004, 3\$171X06059
Dell X1008 Network Switch	4R8XX42, 26SXX42
Dell X1018 Network Switch	6TN7Y42, 63SXX42
Enabling Devices Sip and Puff	[DVS-enabling devices-001] - [DVS-enabling devices- 002]
Cyber Acoustics Headphones ACM-70	[DVS-cyber acoustics-001] - [DVS-cyber acoustics- 005]
4-Way Joystick Controller S26	PME QC 1550 12, [DVS-JOY-001], [DVS-JOY-002]
Enablemart # 88906 Rocker (Paddle) Switch	[DVS-paddle-001]
Dell PowerConnect 2808 Network Switch	3S2P0Z1
IOGEAR SDHC/microSDHC 0U51USC410 Card Reader	8632, 8633
Lexar USB 3.0 Dual-Slot Reader	24020845007435
Hoodman Steel USB 3.0 UDMA Reader 102015	[DVS-hoodman-001]

Component	Serial Number
ATI Handset	98862010101-035, 98862010103-075, 00659010100-
ATTTalldSet	046, 98862010100-232, 093015-1-1, 00659010100-035
ATI-USB Handset	02440010100-011, [DVS-ATIUSB-001], [DVS-
ATI-USD Halidset	ATIUSB-002], B104326-1-4-040, B104326-1-4-035
ACS PC-Linked Smart Card Reader ACR39U	RR374-006272, RR374-010356, RR374-010365
Lexar Professional CF Card Reader	24050361400108, 24050361401994, 24050361401991,
Workflow CFR1	24050361401990
CORCOM Filter P/N#: 15EMC1	[DVS-CorcomEMIFilter-001]
Delta Filter P/N#: 16PDCG5C	[DVS-DeltaEMIFILTER-001]
Kingston Card Reader FCR-HS4	08738174208132

Table 1-29. D-Suite 5.5-B Voting System Support Equipment (continued)

1.1.2 Equipment

In addition to the baseline system hardware identified in Section 1.1.1, the following hardware was required for test performance:

System Component	Hardware Version	
ImageCast Precinct	320A, 320C	
ImageCast Precinct 2	330A	
ImageCast Evolution	410A	
	aValue SID-15V-Z37	
	aValue SID-21V-Z37	
ImageCost V (PMD)	aValue HID-21V-BTX	
ImageCast X (BMD)	HP M402dn	
	HP M402dne	
	HP M501dn	
	aValue HID-21V-BTX	
ImageCost V (DDE)	KFI 702-7520014A (V1)	
ImageCast X (DRE)	KFI 702-7520017C (V1-C)	
	Seiko RP-D10-K27J1-U1C3	
	Canon DR-G1130	
	Canon DR-M160 II	
ImageCast Central	Canon DR-M260	
-	InoTec HiPro 821	
	Canon DR-G2140	

Table 1-30. Hardware

1.2 References

- Election Assistance Commission 2005 Voluntary Voting System Guidelines (VVSG) Version 1.0, Volume I, "Voting System Performance Guidelines", and Volume II, "National Certification Testing Guidelines"
- Election Assistance Commission Testing and Certification Program Manual, Version 2.0

- Election Assistance Commission Voting System Test Laboratory Program Manual, Version 2.0
- National Voluntary Laboratory Accreditation Program NIST Handbook 150, 2016 Edition, "NVLAP Procedures and General Requirements (NIST HB 150-2016)", dated July 2016
- National Voluntary Laboratory Accreditation Program NIST Handbook 150-22, 2008 Edition, "Voting System Testing (NIST Handbook 150-22)", dated May 2008
- United States 107th Congress Help America Vote Act (HAVA) of 2002 (Public Law 107-252), dated October 2002
- Pro V&V, Inc. Quality Assurance Manual, Revision 1.0
- Election Assistance Commission "Approval of Voting System Testing Application Package" letter dated March 20, 2020
- EAC Requests for Interpretation (RFI) (listed on <u>www.eac.gov</u>)
- EAC Notices of Clarification (NOC) (listed on <u>www.eac.gov</u>)
- Dominion Voting Systems Technical Data Package (A listing of the D-Suite 5.5-C documents submitted for this test campaign is listed in Section 3.1.2 of this Test Report)

1.3 Terms and Abbreviations

This subsection lists terms and abbreviations relevant to the hardware, the software, or this Test Plan.

"ADA" – Americans with Disabilities Act 1990

"BMD" - Ballot Marking Device

- "CM" Configuration Management
- "COTS" Commercial Off-The-Shelf
- "DRE" Direct Record Electronic
- "EAC" United States Election Assistance Commission
- "EMS" Election Management System
- "FCA" Functional Configuration Audit
- "HAVA" Help America Vote Act
- "ICC" ImageCast Central
- "ICE" ImageCast Evolution
- "ICP" ImageCast Precinct

"ICX" – ImageCast X

"ISO" - International Organization for Standardization

"NOC" - Notice of Clarification

"PCA" – Physical Configuration Audit

"QA" - Quality Assurance

"RFI" – Request for Interpretation

"TDP" – Technical Data Package

"UPS" – Uninterruptible Power Supply

"VSTL" – Voting System Test Laboratory

"VVPAT" – Voter Verifiable Paper Audit Trail

"VVSG" – Voluntary Voting System Guidelines

2.0 CERTIFICATION TEST BACKGROUND

The Dominion Democracy 5.5-C system is a modification of a previously certified system (D-Suite 5.5-B). Pro V&V performed an evaluation of results from the previous test campaign to determine the scope of testing required for certification of the D-Suite 5.5-B. Based on this evaluation, Pro V&V determined that testing from the previous test campaign would establish the baseline and that the focus of this test campaign would be on the documented system updates.

The list below includes changes between this system and the baseline of the Democracy Suite 5.5-B Voting System.

2.1 Revision History

The table below details the version history of the D-Suite 5.5-C System:

System Version	Certification Type	Baseline System	Certification Number
D-Suite 5.0	New System	(Original System)	DVS-DemSuite5.0
D-Suite 5.5	Modification	D-Suite 5.0	DVS-DemSuite5.5
D-Suite 5.5-B	Modification	D-Suite 5.5	DVS-DemSuite5.5-B
D-Suite 5.5-C	Modification	D-Suite 5.5-B	DVS-DemSuite5.5-C*

Table 2-1. D-Suite 5.5-C System Revision History

*Upon grant of certification by the EAC

2.2 Scope of Testing

The scope of testing focused on the addition of the Canon DR-G2140 central count scanner, the HP M501dn printer for the ICX BMD configuration, and the Microsoft Windows 10 Patch (Jan. 14, 2020). To evaluate the D-Suite 5.5-C test requirements, the submitted modifications were

evaluated against each section of the EAC 2005 VVSG to determine the applicable tests to be performed.

Based on this assessment, it was determined that multiple areas within the EAC 2005 VVSG would be evaluated to encompass the required tests. A breakdown of the areas and associated tests is listed below:

- EAC 2005 VVSG Volume 1, Section 2: Functional Requirements
 - System Integration Testing
 - Functional Configuration Audit (FCA)
 - Physical Configuration Audit (PCA), including System Loads & Hardening
 - Technical Documentation Package (TDP) Review
 - Volume & Stress Testing
 - Accuracy Testing
- EAC 2005 VVSG Volume 1, Section 3: Usability & Accessibility
 - Usability & Accessibility Testing
 - Technical Documentation Package (TDP) Review
- EAC 2005 VVSG Volume 1, Section 4: Hardware Requirements
 - Hardware Testing
 - Technical Documentation Package (TDP) Review
- EAC 2005 VVSG Volume 1, Section 5: Software Requirements
 - Source Code Review, Compliance Build, Trusted Build, and Build Document Review
 - Technical Documentation Package (TDP) Review
 - Functional Configuration Audit (FCA)

2.2.1 Modification Overview

The Dominion Democracy Suite 5.5-C Voting System is a modified voting system configuration that includes upgrades to the components of the D-Suite 5.5-B Voting System. Section 2.2.1.1 details changes between this system and the baseline of the Democracy Suite 5.5-B Voting System. The primary purpose of this modification was to add the Canon DR-G2140 central count scanner, the HP M501dn printer for the ICX BMD configuration, and the Microsoft Windows 10 Patch (Jan. 14, 2020).

To verify the modifications were successfully addressed throughout the test campaign, each modification was tracked and verified to be addressed during the execution of the relevant test area. For example, source code changes were verified during the source code review. Modifications requiring functional test verification were evaluated by executing the standard

TR-01-01-DVS-38-01.02

Accuracy Test, the System Integration Test, or during performance of the FCA. Modifications that were not adequately evaluated during the performance of these tests were subjected to specifically designed test cases. Additionally, Pro V&V functionally verified that any corrected issues from the baseline system were not present in the modified system and that all enhancements implemented did not adversely impact system performance.

2.2.1.1 Detailed List of Changes

GENERAL MODIFICATIONS

- Added the Canon DR-G2140 central count scanner.
- Added the HP M501dn printer for the ICX BMD configuration.
- Added Microsoft Windows 10 Patch (Jan. 14, 2020).

EMS

• Election Summary Report to show party totals for voter turnout and voter registration when ballot rotation and Summary Results files are used.

ADJ

• Added functionality to export the Adjudication Activity Report to CSV format.

ICC

- Corrected issue where certain batches were omitted from ICC Summary Report.
- Corrected functionality to allow discarding of batches after 999.

ICP

• Corrected AuditMark content to show all contests and choices when using multi-card ballots that have multiple instructional contests within an ICX ballot.

ICP2

• Improved paper jam messaging

ICX

- Corrected audio to play the contest title when entering the Straight Party contest.
- Corrected issue where a Non-Partisan option appears on the ballot, even if it's not defined.
- Updated Android OS to remove access to safe mode.
- Added ability to change font for ICX produced ballot.

• Corrected audio instruction on Cast Ballot dialog.

2.2.2 Block Diagram




Figure 1-1. D-Suite 5.5-C System Overview

2.2.3 System Limits

The system limits verified to be supported by the D-Suite 5.5-C System during this test campaign or during testing of the baselined system are provided in the table below.

Characteristic	Limiting Component	Limit	Component
Ballot positions	Ballot	462**/292*	22 in. Ballot
Precincts in an election	EMS	1000; 250	Memory, Standard; Express
Contests in an election	EMS	1000; 250	Memory, Standard; Express
Candidates/Counters in an election	EMS	10000; 2500	Memory, Standard; Express
Candidates/Counters in a precinct	Ballot	462**/240*	22 in. Ballot
Candidates/Counters in a tabulator	Tabulators	10000; 2500	Memory, Standard; Express
Ballot Styles in an election	Tabulators	3000; 750	Memory, Standard; Express
Ballot IDs in a tabulator	ICP	200	Memory, Both EMS
Contests in a ballot style	ICX BMD Ballot	156**/38*	14 in. Ballot, Both EMS
Candidates in a contest	Ballot	231**/240*	22 in. Ballot, Both EMS
Ballot styles in a precinct	Tabulators	5	Memory, Both EMS
Number of political parties	Tabulators	30	Memory, Both EMS
"Vote for" in a contest	Ballot	30**/24*	22 in. Ballot, Both EMS
Supported languages in an election	Tabulators	5	Memory, Both EMS
Number of write-ins	Ballot	462**/24*	22 in. Ballot, Both EMS

Table 2-2. D-Suite 5.5-C System Limits by Configuration

* Reflects the system limit for a ballot printed in landscape

** Reflects the system limit for a ballot printed in portrait.

2.2.4 Supported Languages

Support for the following languages was verified during this test campaign or during testing of the baselined system:

Language	ICE	ICP	ICP2	ICX
Alaska Native	Yes, if using Latin alphabet	Yes	No	No
Apache	Audio only	Audio only	No	No
Bengali	Yes	Yes	Yes	Yes
Chinese	Yes	Yes	Yes	Yes
English	Yes	Yes	Yes	Yes
Eskimo	Yes, if using Latin alphabet	Yes	No	No
Filipino	Yes, if using Latin alphabet	Yes	Yes	No

 Table 2-3. D-Suite 5.5-C Supported Languages

Language	ICE	ICP	ICP2	ICX
French	Yes	Yes	No	Yes
Hindi	Yes	Audio only	Yes	Yes
Japanese	Yes	Yes	Yes	Yes
Jicarilla	Audio only	Audio only	No	No
Keres	Audio only	Audio only	No	No
Khmer	Yes	Audio only	No	No
Korean	Yes	Yes	Yes	Yes
Navajo	Audio only	Audio only	No	No
Seminole	Audio only	Audio only	No	No
Spanish	Yes	Yes	Yes	Yes
Tagalog	No	No	No	Yes
Thai	Yes	Audio only	Yes	Yes
Towa	Audio only	Audio only	No	No
Ute	Audio only	Audio only	No	No
Vietnamese	Yes	Yes	Yes	Yes
Yuman	Audio only	Audio only	No	No

 Table 2-3. D-Suite 5.5-C Supported Languages (continued)

Support for all stated languages was verified; however, only English and Spanish language ballots were cast during the performance of functional testing. Additionally, one character based language (Chinese) was tested during System Integration Testing.

For the character based language, the ballot was created by Pro V&V and voted utilizing both paper ballots and ADA voting devices along with all applicable peripherals. The Chinese Language for the ballot was created using a readily available online translation tool. The translated language text was entered into the Election Event Designer Application. A ballot preview was generated in the EED application. The Chinese characters displayed in the ballot preview were compared to the characters generated by the online translation tool, to ensure that the characters matched. The ballots were then generated and printed, and the election loaded onto the tabulators and the BMD units. The Chinese characters displayed on both the printed ballots and displayed on the BMD units were compared to the original Chinese Characters generated by the online translation tool to verify that the characters matched.

2.2.5 Supported Functionality

The D-Suite 5.5-C was verified to support the following voting variations:

- General Election
- Closed Primary
- Open Primary
- Early Voting
- Partisan/Non-Partisan Offices
- Write-In Voting

- Primary Presidential Delegation Nominations
- Split Precincts
- Vote for N of M
- Ballot Rotation
- Provisional or Challenged Ballots

2.2.6 VVSG

The D-Suite 5.5-C Voting System was evaluated against the relevant requirements contained in the EAC 2005 VVSG, Version 1.0.

2.2.7 **RFIs**

There are no RFIs released by the EAC as of the date of this Test Report that pertain to this test campaign that were not in effect at the time of the baseline system certification.

2.2.8 NOCs

There are no NOCs released by the EAC as of the date of this Test Report that pertain to this test campaign that were not in effect at the time of the baseline system certification.

3.0 TEST FINDINGS AND RECOMMENDATION

The D-Suite 5.5-C Voting System was evaluated against the relevant requirements contained in the EAC 2005 VVSG, Volumes I and II. The focus of this test campaign is the addition of the Canon DR-G2140 central count scanner, the HP M501dn printer for the ICX BMD configuration, and the Microsoft Windows 10 Patch (Jan. 14, 2020). The summary findings and recommendations for each area of testing are provided in the following sections.

3.1 Summary Findings and Recommendation

Summary findings for the System Level Testing (System Integration Testing, Accuracy Test, Volume & Stress Testing, and FCA), Hardware Testing, Usability & Accessibility Testing, Security Testing, and Source Code Review are detailed in the relevant sections of this report. In addition to these areas of testing, a PCA (including System Loads & Hardening), a TDP Review, and a QA & CM System Review were performed, as described below.

3.1.1 Physical Configuration Audit (PCA)

The Physical Configuration Audit (PCA) compares the voting system components submitted for qualification to the manufacturer's technical documentation, and shall include the following activities:

• Establish a configuration baseline of software and hardware to be tested; confirm whether manufacturer's documentation is sufficient for the user to install, validate, operate, and maintain the voting system

- Verify software conforms to the manufacturer's specifications; inspect all records of manufacturer's release control system; if changes have been made to the baseline version, verify manufacturer's engineering and test data are for the software version submitted for certification
- If the hardware is non-COTS, Pro V&V shall review drawings, specifications, technical data, and test data associated with system hardware to establish system hardware baseline associated with software baseline
- Review manufacturer's documents of user acceptance test procedures and data against system's functional specifications; resolve any discrepancy or inadequacy in manufacturer's plan or data prior to beginning system integration functional and performance tests
- Subsequent changes to baseline software configuration made during testing, as well as system hardware changes that may produce a change in software operation are subject to re-examination

Summary Findings

During execution of the PCA, the components of the D-Suite 5.5-C were documented by component name, model, serial number, major component, and any other relevant information needed to identify the component. For COTS equipment, every effort was made to verify that the COTS equipment had not been modified for use. Additionally, each technical document submitted in the TDP was recorded by document name, description, document number, revision number, and date of release. At the conclusion of the test campaign, test personnel verified that any changes made to the software, hardware, or documentation during the test process were fully and properly documented.

3.1.2 TDP Review

In order to determine compliance of the modified TDP documents with the EAC 2005 VVSG, a limited TDP review was conducted. This review focused on TDP documents that have been modified since the certification of the baseline system. The review consisted of a compliance review to determine if each regulatory, state, or manufacturer-stated requirement had been met based on the context of each requirement. Results of the review of each document were entered on the TDP Review Checklist and reported to the manufacturer for disposition of any anomalies. This process was ongoing until all anomalies were resolved.

Summary Findings

The submitted TDP was determined to be in compliance with the requirements set forth in the EAC 2005 VVSG. A listing of all documents contained in the D-Suite 5.5-C TDP is provided in Table 3-1.

Document Number	Description	Version			
	Adjudication Documents				
2.05	Democracy Suite Adjudication Software Design and Specification	5.5-C::138			
2.08	Democracy Suite Adjudication System Operation Procedures	5.5-C::185			
2.09	Democracy Suite Adjudication System Maintenance Manual	5.5-C::119			
	D-Suite Documents				
2.02	Democracy Suite System Overview	5.5-C::196			
2.06	Democracy Suite System Security Specification	5.5-C::586			
2.07	Democracy Suite System Test and Verification	5.5-C::209			
2.10	Democracy Suite Personnel Deployment and Training Requirements	5.5-C::145			
2.11	Democracy Suite Configuration Management Process	5.5-C::435			
2.12	Democracy Suite Quality Assurance Program	5.5-C::173			
2.13	Democracy Suite System Change Notes	5.5-C::191			
	EMS Documents				
2.03	Democracy Suite EMS Functional Description	5.5-C::396			
2.05	Democracy Suite EMS Software Design and Specification	5.5-C::344			
2.08	Democracy Suite EMS System Operations Procedures	5.5-C::744			
2.09	Democracy Suite EMS System Maintenance Manual	5.5-C::163			
	Democracy Suite EMS System Installation and Configuration Procedure	5.5-C::385			
ImageCast Central Documents					
2.03	Democracy Suite ImageCast Central Functionality Description	5.5-C::209			
2.05	Democracy Suite ImageCast Central Software Design and Specification	5.5-C::137			
2.08	Democracy Suite ImageCast Central System Operation Procedures	5.5-C::226			
	Democracy Suite ImageCast Central Installation and Configuration Procedure	5.5-C::254			
	ImageCast Evolution Documents				
2.03	Democracy Suite ImageCast Evolution Functionality Description	5.5-C::129			
2.04	Democracy Suite ImageCast Evolution System Hardware Specifications	5.5-C::338			
2.05	Democracy Suite ImageCast Evolution Software Design and Specifications	5.5-C::183			
2.08	Democracy Suite ImageCast Evolution System Operation Procedures	5.5-C::251			
2.09	Democracy Suite ImageCast Evolution System Maintenance Manual				

Table 3-1. TDP Documents

Document Number	Description	Version
	ImageCast Precinct Documents	
2.03	Democracy Suite ImageCast Precinct Functionality Description	5.5-C::197
2.04	Democracy Suite ImageCast Precinct System Hardware Specification	5.5-C::167
2.04.1	Democracy suite ImageCast Precinct System Hardware Characteristics	5.5-C::112
2.05	Democracy Suite ImageCast Precinct Software Design and Specification	5.5-C::169
2.08	Democracy Suite ImageCast Precinct System Operation Procedures	5.5-C::296
2.09	Democracy Suite ImageCast Precinct System Maintenance Manual	5.5-C::140
	ImageCast Precinct2 Documents	
2.03	Democracy Suite ImageCast Precinct 2 Functionality Description	5.5-C::14
2.04	Democracy Suite ImageCast Precinct 2 System Hardware Specifications	5.5-C::15
2.05	Democracy Suite ImageCast Precinct 2 Software Design and Specifications	5.5-C::20
2.08	Democracy Suite ImageCast Precinct 2 System Operation Procedures	5.5-C::22
2.09	Democracy Suite ImageCast Precinct 2 System Maintenance Manual	5.5-C::16
	ImageCast X Documents	
2.03	Democracy Suite ImageCast X Functionality Description	5.5-C::97
2.05	Democracy Suite ImageCast X Software Design and Specification	5.5-C::100
2.08	Democracy Suite ImageCast X System Operation Procedures	5.5-C::88
	Democracy Suite ImageCast X System Installation and Configuration	5.5-C::94
2.09	Democracy Suite ImageCast X System Maintenance Manual	5.5-C::79
	User Guides	
	Democracy Suite ImageCast Adjudication User Guide	5.5-C::142
	Democracy Suite Election Data Translator User Guide	5.5-C::90
	Democracy Suite EMS Audio Studio User Guide	5.5-C::39
	Democracy Suite EMS Automated Test Deck User Guide	
	Democracy Suite EMS Election Event Designer User Guide	
	Democracy Suite EMS Results Tally and Reporting User Guide	5.5-C::146
	Democracy Suite ImageCast Central User Guide	5.5-C::138
	Democracy Suite ImageCast Precinct User Guide	5.5-C::58
	Democracy Suite ImageCast Voter Activation User Guide	
	1	

Document Number	Description	Version
	Democracy Suite ImageCast X User Guide	5.5-C::253
	Democracy Suite ImageCast Precinct 2 User Guide	5.5-C::8
	DVS Supplementary Documents	
	Democracy Suite ImageCast C++ Coding Standard	5.5-C::73
	Democracy Suite C# Automated Code Review Process	5.5-C::68
	Google Java Style Dominion XML	
	Dominion Voting Systems Java Coding Standards	1.0
	Dominion Voting Systems JavaScript Coding Standards	1.0
	Democracy Suite ImageCast Evolution Firmware Installation Procedure	5.5-C::106
	Democracy Suite ImageCast Device Configuration Files	5.5-C::117
	Democracy Suite ImageCast Evolution Level One (L1) Maintenance Manual	5.5-C::140
	Democracy Suite ImageCast Election Definition Files	5.5-C::98
	Democracy Suite ImageCast Evolution Machine Behavior Settings	5.5-C::106
	Usability Study of Dominion Voting Systems ImageCast Evolution Versions 4.1.1.1 and 4.6.1.1	
	Democracy Suite ImageCast Precinct Extracting Firmware Contents	5.5-C::54
	Democracy Suite ImageCast Precinct Firmware Update Procedure	5.5-C::85
	Democracy Suite ImageCast Precinct Level One (L1) Maintenance Manual	5.5-C::80
	Democracy Suite ImageCast Precinct Technical Guide	5.5-C::67
	Usability Test Report of ImageCast Precinct 5.0 with 36 Participants for VVSG 1.0	5.0::10
	Usability Test Report of ImageCast X 5.0 with 36 Participants for VVSG 1.0	5.0::13
	Democracy Suite ImageCast Precinct 2 Level One (L1) Maintenance Manual	5.5-C:22
	Democracy Suite ImageCast Precinct 2 Machine Behavior Settings	5.5-C::19
	ICX Machine Configuration File (MCF) Parameters Settings	5.5-C::32
	Common Industry Format for Usability Test Report ImageCast X 5.2 with VVPAT	5.5::1
	Democracy Suite System Identification Guide	5.5-C::384
	Democracy Suite ImageCast Total Results File Format	5.5-C::74
	Democracy Suite ImageCast Printing and Finishing Specification	5.5-C::118
	COTS Supplemental	

Ablenet Single Switch Quickstart Guide B ACS ACOS6 Multi-Application and Purse Card Functional 1.04 ACS ACR38x CCID Smart Card Reader Reference Manual 6.05 ACS ACR39 Series PC-linked Smart Card Readers Reference 1.04 ACS ACR39 Series PC-linked Smart Card Readers Reference 1.04 ACS USB Monitor User Manual E1659Fwu n/a APC Installation and Operation Back-UPS Pro BR1000G EN 990- APC Installation and Operation Rack Power Distribution Unit 990 APC Operation Manual Smart-UPS Uninterruptible Power Supply 3534F APC Operation Manual Smart-UPS Uninterruptible Power Supply 5442B APC Smart-UPS Installation Guide SMT1500 20 S355F-001 APC User Manual Back-UPS BE600M1 EN 990- aValue HID-21V-BTX Factsheet n/a aValue SID-15V Quick Reference Guide 1st Ed aValue SID-15V Z37-A1R User Manual 1.0 aValue SID-21V Z37-A1R User Manual <t< th=""><th>Document Number</th><th>Description</th><th>Version</th></t<>	Document Number	Description	Version
Image: Specifications 1.04 ACS ACR38x CCID Smart Card Reader Reference Manual 6.05 ACS ACR39 Series PC-linked Smart Card Readers Reference Manual 1.04 ACS CUSB Monitor User Manual E1659Fwu n/a AOC USB Monitor User Manual E1659Fwu n/a APC Installation and Operation Back-UPS Pro BR1000G 3804B APC Installation and Operation Rack Power Distribution Unit 990. APC Operation Manual Smart-UPS Uninterruptible Power Supply 5834F APC Operation Manual Smart-UPS Uninterruptible Power Supply 58442B APC Operation Manual Back-UPS BE600M1 EN 990. APC Smart-UPS Installation Guide SMT1500 EN 990. APC User Manual Back-UPS BE600M1 5679 aValue HID-21V-BTX Factsheet n/a aValue SID-15V Quick Reference Guide 1st Ed aValue SID-15V-237-A1R User Manual 1.0 aValue SID-21V Patts Alt User Manual 1.0 aValue SID-21V Vaits Reference Guide 1st Ed aValue SID-21V Quick Reference Guide 1st Ed aValue SID-21V Quick Reference Guide 10.0 aV		Ablenet Single Switch Quickstart Guide	В
ACS ACR39 Series PC-linked Smart Card Readers Reference Manual 1.04 AOC USB Monitor User Manual E1659Fwu n/a APC Installation and Operation Back-UPS Pro BR1000G 3804B APC Installation and Operation Back-UPS Pro BR1000G 3804B APC Installation and Operation Rack Power Distribution Unit AP9562 990- APC Operation Manual Smart-UPS Uninterruptible Power Supply 5534F APC Operation Manual Smart-UPS Uninterruptible Power Supply 5442B APC Smart-UPS Installation Guide SMT1500 EN 990- APC User Manual Back-UPS BE600M1 EN 990- APC User Manual Back-UPS BE600M1 EN 990- aValue HID-21V-BTX Factsheet n/a aValue BID-15V Quick Reference Guide 1st Ed aValue SID-21V Quick Reference Guide 1st Ed aValue SID-21V-Z37-A1R User Manual 1.0 aValue SID-21V Quick Reference Guide 1st Ed aValue SID-21V-Z37-A1R User Manual 1.0 aValue SID-21V-Z37-A1R User Manual 1.0 <td< td=""><td></td><td></td><td>1.04</td></td<>			1.04
Manual1.04AOC USB Monitor User Manual E1659Fwun/aAPC Installation and Operation Back-UPS Pro BR1000GEN 990- 3804BAPC Installation and Operation Rack Power Distribution Unit AP9562990- 1215D001APC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 5442BAPC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 3534FAPC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 3535F-001APC Smart-UPS Installation Guide SMT1500EN 990- 3535F-001APC User Manual Back-UPS BE600M1EN 990- 3535F-001aValue HID-21V-BTX Factsheetn/aaValue HID-21V-BTX Factsheetn/aaValue SID-15V Quick Reference Guide1st EdaValue SID-15V-Z37-A1R User Manual1.0aValue SID-21V Fact Sheetn/aaValue SID-21V Yact Sheetn/aaValue SID-21V-Z37-A1R User Manual1.0aValue SID-21V-Z37-A1R User Manual1.0canon DR-G1130 User GuideGT3-0034- E1.10Canon DR-G1130 User GuideCE-IM- 		ACS ACR38x CCID Smart Card Reader Reference Manual	6.05
APC Installation and Operation Back-UPS Pro BR1000GEN 990- 3804BAPC Installation and Operation Rack Power Distribution Unit AP9562990- 1215D001APC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 3534FAPC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 3534FAPC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 3535F-001APC Smart-UPS Installation Guide SMT1500EN 990- 3535F-001APC User Manual Back-UPS BE600M1EN 990- 3535F-001aValue HID-21V-BTX Factsheetn/aaValue HID-21V-BTX Factsheetn/aaValue SID-15V Quick Reference Guide1st EdaValue SID-15V Quick Reference Guide1st EdaValue SID-21V Fact Sheetn/aaValue SID-21V Vact Sheetn/aaValue SID-21V-Z37-A1R User Manual1.0aValue SID-21V-Z37-A1R User Manual1.0aValue SID-21V Quick Reference Guide1st EdaValue SID-21V Quick Reference Guide1st Edcanon DR-G1130 User GuideCE-IM- 910-E1.10Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M260 User ManualCE-IM- 0953-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphones			1.04
APC Installation and Operation Back-UPS Pro BR1000G3804BAPC Installation and Operation Rack Power Distribution Unit AP9562990- 1215D001APC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 3534FAPC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 3534FAPC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 3535F-001APC User Manual Back-UPS BE600M1EN 990- 3535F-001aValue HID-21V-BTX Factsheetn/aaValue HID-21V-BTX Factsheetn/aaValue SID-15V Quick Reference Guide1st EdaValue SID-15V Quick Reference Guide1st EdaValue SID-21V Fact Sheetn/aaValue SID-21V Quick Reference Guide1st EdaValue SID-21V Quick Reference Guide1st EdaValue SID-21V Quick Reference Guide1st EdaValue SID-21V Quick Reference Guide10.0Canon DR-G1130 User GuideCE-IM- 0910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3400 Nener's Manu		AOC USB Monitor User Manual E1659Fwu	n/a
AP95621215D001APC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 3534FAPC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 5442BAPC Smart-UPS Installation Guide SMT1500EN 990- 3535F-001APC User Manual Back-UPS BE600M1EN 990- 5679aValue HID-21V-BTX Factsheetn/aaValue HID-21V-BTX Factsheetn/aaValue SID-15V Quick Reference Guide1st EdaValue SID-15V Quick Reference Guide1st EdaValue SID-21V Fact Sheetn/aaValue SID-21V Z37-A1R User Manual1.0aValue SID-21V Z37-A1R User Manual1.0aValue SID-21V Quick Reference Guide1st EdaValue SID-21V-Z37-A1R User Manual1.0canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3480 Owner's ManualRev. A00		APC Installation and Operation Back-UPS Pro BR1000G	
APC Operation Manual Smart-UPS Uninterruptible Power Supply3534FAPC Operation Manual Smart-UPS Uninterruptible Power SupplyEN 990- 5442BAPC Smart-UPS Installation Guide SMT1500EN 990- 3535F-001APC User Manual Back-UPS BE600M1EN 990- 5679aValue HID-21V-BTX Factsheetn/aaValue HID-21V-BTX-A1R User Manual2.0aValue SID-15V Quick Reference Guide1st EdaValue SID-15V Quick Reference Guide1st EdaValue SID-21V Fact Sheetn/aaValue SID-21V Vick Reference Guide1st EdaValue SID-21V Vick Reference Guide1st EdaValue SID-21V Vick Reference Guide1.0canon DR-G1130 User Guide010-CE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M260 User ManualCE-IM- 0953-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3480 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		•	
APC Operation Manual Smart-UPS Uninterruptible Power Supply5442BAPC Smart-UPS Installation Guide SMT1500EN 990- 3535F-001APC User Manual Back-UPS BE600M1EN 990- 5679aValue HID-21V-BTX Factsheetn/aaValue HID-21V-BTX-A1R User Manual2.0aValue SID-15V Quick Reference Guide1st EdaValue SID-15V Quick Reference Guide1st EdaValue SID-21V Fact Sheetn/aaValue SID-21V-Z37-A1R User Manual1.0aValue SID-21V-Z37-A1R User Manual1.0aValue SID-21V-Z37-A1R User Manual1.0canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User Manual0953-E1.00Canon DR-M260 User Manual025-3F-1.00Canon imageClass LBP6230dw Spec Sheetn/aCyber Acoustics ACM-70B Stereo Headphonesn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3480 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		APC Operation Manual Smart-UPS Uninterruptible Power Supply	
APC Smart-UPS Installation Guide SM115003535F-001APC User Manual Back-UPS BE600M1EN 990- 5679aValue HID-21V-BTX Factsheetn/aaValue HID-21V-BTX-A1R User Manual2.0aValue SID-15V Quick Reference Guide1st EdaValue SID-15V Quick Reference Guide1st EdaValue SID-21V Fact Sheetn/aaValue SID-21V Quick Reference Guide1st EdaValue SID-21V Quick Reference Guide1st EdaValue SID-21V Quick Reference Guide1.0aValue SID-21V-Z37-A1R User Manual1.0canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M160II User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCyber Acoustics ACM-70B Stereo Headphonesn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3400 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		APC Operation Manual Smart-UPS Uninterruptible Power Supply	5442B
APC User Manual Back-UPS BE600M15679aValue HID-21V-BTX Factsheetn/aaValue HID-21V-BTX-A1R User Manual2.0aValue SID-15V Quick Reference Guide1st EdaValue SID-15V-Z37-A1R User Manual1.0aValue SID-21V Fact Sheetn/aaValue SID-21V Quick Reference Guide1st EdaValue SID-21V Quick Reference Guide1st EdaValue SID-21V-Z37-A1R User Manual1.0canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M160II User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3480 Owner's ManualRev. A00		APC Smart-UPS Installation Guide SMT1500	3535F-001
aValue HID-21V-BTX-A1R User Manual2.0aValue SID-15V Quick Reference Guide1st EdaValue SID-15V-Z37-A1R User Manual1.0aValue SID-21V Fact Sheetn/aaValue SID-21V Quick Reference Guide1st EdaValue SID-21V Quick Reference Guide1st EdaValue SID-21V-Z37-A1R User Manual1.0aValue SID-21V-Z37-A1R User Manual1.0Canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User Manual0953-E1.00Canon DR-M160II User Manual0953-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3480 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		APC User Manual Back-UPS BE600M1	
aValue SID-15V Quick Reference Guide1st EdaValue SID-15V-Z37-A1R User Manual1.0aValue SID-21V Fact Sheetn/aaValue SID-21V Fact Sheetn/aaValue SID-21V Quick Reference Guide1st EdaValue SID-21V-Z37-A1R User Manual1.0aValue SID-21V-Z37-A1R User Manual1.0Canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M160II User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3480 Owner's ManualRev. A00		aValue HID-21V-BTX Factsheet	n/a
aValue SID-15V-Z37-A1R User Manual1.0aValue SID-21V Fact Sheetn/aaValue SID-21V Quick Reference Guide1st EdaValue SID-21V-Z37-A1R User Manual1.0aValue SID-21V-Z37-A1R User Manual1.0Canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M160II User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3480 Owner's ManualRev. A00		aValue HID-21V-BTX-A1R User Manual	2.0
aValue SID-21V Fact Sheetn/aaValue SID-21V Quick Reference Guide1st EdaValue SID-21V-Z37-A1R User Manual1.0Canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M160II User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3480 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		aValue SID-15V Quick Reference Guide	1st Ed
aValue SID-21V Quick Reference Guide1st EdaValue SID-21V-Z37-A1R User Manual1.0Canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M260 User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		aValue SID-15V-Z37-A1R User Manual	1.0
aValue SID-21V-Z37-A1R User Manual1.0Canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M160II User ManualCE-IM- 09953-E1.00Canon DR-M260 User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3480 Owner's ManualRev. A00		aValue SID-21V Fact Sheet	n/a
Canon DR-G1130 User GuideCE-IM- 910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M160II User ManualCE-IM- 0991-E1.00Canon DR-M260 User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		aValue SID-21V Quick Reference Guide	1st Ed
Canon DR-G1130 User Guide910-E1.00Canon DR-G2140 DR-G2110 DR-2090 User Manual6T3-0034- E1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M260 User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		aValue SID-21V-Z37-A1R User Manual	1.0
Canon DR-G2140 DR-G2110 DR-2090 User ManualE1.10Canon DR-M160II User ManualCE-IM- 0953-E1.00Canon DR-M260 User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		Canon DR-G1130 User Guide	-
Canon DR-M160II User Manual0953-E1.00Canon DR-M260 User ManualCE-IM- 0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		Canon DR-G2140 DR-G2110 DR-2090 User Manual	
Canon DR-M260 User Manual0991-E1.00Canon imageClass LBP6230dw Spec Sheetn/aCanon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		Canon DR-M160II User Manual	
Canon imageClass LBP6230dw Startupn/aCyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		Canon DR-M260 User Manual	
Cyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		Canon imageClass LBP6230dw Spec Sheet	n/a
Cyber Acoustics ACM-70B Stereo Headphonesn/aCyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00		Canon imageClass LBP6230dw Startup	n/a
CyberPower Smart App Sinewave Series PR1500LCD User's Manualn/aDell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00			n/a
Dell Latitude 3400 Setup and specifications guideRev. A00Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00			n/a
Dell Latitude 3470 Owner's ManualRev. A00Dell Latitude 3480 Owner's ManualRev. A00			Rev. A00
Dell Latitude 3480 Owner's Manual Rev. A00			
		Dell Latitude 3490 Owner's Manual	Rev. A01

Table 3-1	. TDP	Documents	(continued)
-----------	-------	------------------	-------------

Document Number	Description	Version
	Dell Latitude E7450 Owner's Manual	Rev. A02
	Dell Latitude E7470 Owner's Manual	Rev. A02
	Dell Networking X1000 and X4000 Series Switches User Guide	Rev. A06
	Dell Networking X-Series Spec Sheet	1.9
	Dell OptiPlex 3050 All-in-One Owner's Manual	Rev. A00
	Dell OptiPlex 5270 All-in-One Setup and specifications guide	Rev. A00
	Dell OptiPlex 7050 Tower Owner's Manual	Rev. A01
	Dell OptiPlex 7060 Small form Factor Setup and specifications guide	Rev. A01
	Dell OptiPlex 7070 Tower Setup and Specifications	Rev. A00
	Dell OptiPlex 7440 All-In-One Owner's Manual	Rev. A01
	Dell OptiPlex 9010/7010 Desktop Owner's Manual	Rev. A02
	Dell OptiPlex 9020 Small Form Factor Owner's Manual	Rev. A01
	Dell OptiPlex 9030 All-In-One Owner's Manual	Rev. A01
	Dell P2417H Monitor User's Guide	Rev. A01
	Dell P2418HT User's Guide	Rev. A00
	Dell P2419H Monitor User's Guide	Rev. A00
	Dell PowerEdge R330 Owner's Manual	Rev. A02
	Dell PowerEdge R340 Installation and Service Manual	Rev. A00
	Dell PowerEdge R340 Technical Specifications Guide	Rev. A00
	Dell PowerEdge R620 Owner's Manual	Rev. A05
	Dell PowerEdge R630 Data Sheet	A10
	Dell PowerEdge R630 Owner's Manual	Rev. A03
	Dell PowerEdge R640 Installation and Service Manual	Rev. A01
	Dell PowerEdge R640 Technical Guide	
	Dell PowerEdge T640 Installation and Service Manual	Rev. A08
	Dell Precision 3430 Small form Factor Service Manual	Rev. A00
	Dell Precision 3431 Small Form Factor Setup and specifications guide	Rev. A00
	Dell Precision T1700 Mini-Tower Owner's Manual	Rev. A00
	Dell Precision T3420 Owner's Manual	Rev. A00
	DisplayLink DL-1x5 Series High Performance USB Virtual Graphics	n/a
	HIC++ Standards Model for C++	9.5.4
	HP LaserJet Pro M402, M403 User Guide	2.0
	HP LaserJet Pro M402dn Datasheet	Rev. 2
	HP LaserJet Pro M402dne Datasheet	n/a
	HP LaserJet Pro M501 User Guide	3.0
	KFI VRP3 User Manual Safety precautions	n/a
	Kingston USB 3.0 High-Speed Media Reader	n/a

Document Number	Description	Version	
	Lenovo ThinkCentre TIO24Gen3Touch User Guide	1st Ed	
	Lexar Professional USB 3.0 Dual-Slot Reader	n/a	
	Programming Research High-Integrity C++ Coding Standard Manual	2.2	
	SCAMAX 8x1 Ultra High Performance Scanner	n/a	
	SCAMAX Document Scanner User Manual Type:H12	2019.12	
	Seiko SII Thermal Printer RP-D10 Series User's Guide	n/a	
	Tripp Lite SmartPro Data Sheet	n/a	
Build Documents			
	Democracy Suite ImageCast Evolution Firmware Build, Prerequisite Setup and Installation	5.5-C::102	
	Democracy Suite ImageCast Precinct Firmware Build and Install	5.5-C::111	
	Democracy Suite ImageCast X Build	5.5-B::56	
	Democracy Suite Windows Build Document	5.5-C::48	
	Democracy Suite ImageCast Precinct 2 Build Environment and Prerequisite Setup, Firmware Build and Installation	5.5-C::31	

3.1.3 QA & CM System Review

The Dominion Voting Systems Quality and Configuration Management Manuals were reviewed for their fulfillment of Volume I, Sections 8 and 9, and the requirements specified in Volume II, Section 2. The requirements for these sections establish the quality assurance and configuration standards for voting systems to which manufacturers must conform and require voting system manufacturers to implement a quality assurance and configuration management program that is conformant with recognized ISO standards. As part of the review process, the Dominion Voting Systems TDP documents were reviewed to determine if the stated policies were being followed.

Summary Findings

This testing utilized the TDP Review in conjunction with the PCA to determine compliance to the EAC 2005 VVSG requirements and the requirements stated in the Dominion Voting Systems technical documentation. The review of the Quality Assurance and Configuration Management documentation focused on the Dominion Voting Systems' adherence to its stated QA and CM processes. No discrepancies were noted during the reviews.

3.1.4 Source Code Review, Compliance Build, Trusted build, and Build Documentation Review

Pro V&V reviewed the submitted source code to the EAC 2005 VVSG and the manufacturersubmitted coding standards. Prior to initiating the software review, Pro V&V verified that the submitted documentation was sufficient to enable: (1) a review of the source code and (2) Pro V&V to design and conduct tests at every level of the software structure to verify that design specifications and performance guidelines are met. For the ICE software, a combination of Automated Source Code Review and Manual Source Code Review methods was used to review the source code. For all other components, the submitted source code was compared to the previously certified Democracy Suite 5.5-B voting system versions to determine the changes, if any. A combination of Automated Source Code Review and Manual Source Code Review methods was used to review the changes in the source code. In addition, 10% of the source code comments were manually reviewed.

Summary Findings

- <u>Automated Source Code Review</u>: The Automated Source Code Review was performed to review the changes in the source code from the previously certified voting system. No source code issues were found during the Automated Source Code review.
- <u>Manual Source Code Review</u>: The Manual Source Code review was performed on 10% of the comments for compliance to VVSG Volume 1 Section 5.2.7. No source code issues were found during the Manual Source Code review.
- <u>Compliance Build</u>: The compliance build was performed following the compliance review. Once the compliance review was performed and the source was deemed stable enough to proceed with testing, the source code and all additional packages were compiled into a Compliance Build.

<u>Trusted Build</u>: The trusted build consisted of inspecting customer submitted source code, COTS, and Third Party software products and combining them to create the executable code. This inspection followed the documented process from the "United States Election Assistance Commission Voting System Testing and Certification Program Manual" Section 5.5 - 5.7. Performance of the trusted build includes the build documentation review. The Trusted Build was performed following the completion of the Functional Configuration Audit.

3.1.5 System Level Testing

System Level testing was implemented to evaluate the complete system. This testing included all proprietary components and COTS components (software, hardware, and peripherals) in a configuration of the system's intended use. For software system tests, the tests were designed according to the stated design objective without consideration of its functional specification. The system level hardware and software test cases were prepared independently to assess the response of the hardware and software to a range of conditions. Pro V&V reviewed the manufacturer's program analysis, documentation, and module test case design and evaluated the test cases for each module with respect to flow control parameters and entry/exit data.

System Level Testing included the evaluations of the following test areas FCA, Accuracy Testing, Volume & Stress, and System Integration Testing. Each of these areas is reported in detail in the subsections that follow.

Component Level Testing was implemented during the FCA for each component and subcomponent. During the source code review, compliance builds, and security testing, Pro

V&V utilized limited structural-based techniques (white-box testing). Additionally, specificationbased techniques (black-box testing) were utilized for the individual software components.

Pro V&V defined the expected result for each test and the ACCEPT/REJECT criteria for certification. If the system performed as expected, the results were accepted. If the system did not perform as expected, an analysis was performed to determine the cause. If needed, the test was repeated in an attempt to reproduce the results. If the failure could be reproduced and the expected results were not met, the system was determined to have failed the test. If the results could not be reproduced, the test continued. Any errors encountered were documented and tracked through resolution.

To verify the modifications were successfully addressed throughout the test campaign, each modification was tracked and verified to be addressed during the execution of the relevant test area. For example, source code changes were verified during the source code review. Modifications requiring functional test verification were evaluated by executing the standard Accuracy Test, the System Integration Test, or during performance of the FCA. Modifications that were not adequately evaluated during the performance of these tests were subjected to specifically designed test cases.

3.1.5.1 Functional Configuration Audit (FCA)

The functional configuration audit encompasses an examination of manufacturer's tests, and the conduct of additional tests, to verify that the system hardware and software perform all the functions described in the manufacturer's documentation submitted in the TDP.

In addition to functioning according to the manufacturer's documentation, tests will be conducted to insure all applicable EAC 2005 VVSG requirements are met.

For this campaign FCA testing included several exhaustive paths applied in concert:

- <u>FCA-VVSG Testing</u>: Each component of the system was evaluated against a standardized testcase suite centered upon requirements stated in the VVSG and administered through a testmanagement software tool. All applicable tests-cases were performed while any non-applicable test-cases were logged as "n/a" for substantiation. The system operations and functional capabilities were categorized in the tool as follows by the phase of election activity in which they are required:
 - <u>Pre-voting Capabilities</u>: These functional capabilities are used to prepare the voting system for voting. They include ballot preparation, the preparation of election-specific software (including firmware), the production of ballots, the installation of ballots and ballot counting software (including firmware), and system and equipment tests.
 - <u>Voting System Capabilities</u>: These functional capabilities include all operations conducted at the polling place by voters and officials including the generation of status messages.
 - <u>Post-voting Capabilities</u>: These functional capabilities apply after all votes have been cast. They include closing the polling place; obtaining reports by voting machine, polling place,

and precinct; tabulation of paper ballots at the central location; accumulation of results from all voting methods; obtaining consolidated reports; and obtaining reports of audit trails.

- <u>FCA-Claims Testing</u>: System user instructions and procedures found in the TDP were followed to verify their accuracy and completeness. In addition any functional claims discovered in the TDP that were not specifically examined in other areas or that were items of interest were also tested.
- <u>FCA-Mapping:</u> Any modified functional paths (buttons, dropdowns, etc.) were mapped by qualified VSTL personnel, to help ensure all functional options had been noted and exercised. Any items of interest were examined and/or tested.

All issues (if any) found during these efforts are detailed in Section 3.3. Any issues noted were tracked using an issue tracking software program and issue tracking spreadsheets.

Summary Findings

All functional tests were successfully executed. During execution of the test procedure, it was verified that the D-Suite 5.5-C System successfully completed the system level integration tests with all actual results obtained during test execution matching the expected results.

3.1.5.2 Volume & Stress

The Volume & Stress Tests are utilized to investigate the system's response to conditions that tend to overload the system's capacity to process, store, and report data.

The test parameters focused on the system's stated limits and the ballot logic for areas such as the maximum number of active voting positions, maximum number of ballot styles, maximum candidates, maximum contests, and stated limits within the EMS. This test is utilized to ensure the system could achieve the manufacturer's TDP claims of what the system can support. Testing was performed by exercising multiple election definitions and test cases developed specifically to test for volume and stress conditions of the system being tested.

Summary Findings

Volume and Stress test results from previous test campaigns were utilized to meet the requirements of this test campaign. Test results for the ICX BMD, ICX DRE, ICE, ICX DRE with VVPAT, ICP, ICP2, and ICC were reused from the D-Suite 5.5-B EAC Campaign. Test results for the Canon DR-G2140 were reused from the Democracy Suite 5.5-A (ECO 100647) state test campaign performed by Pro V&V per the VVSG.

3.1.5.3 Accuracy

The accuracy test ensures that each component of the voting system can each process 1,549,703 consecutive ballot positions correctly within the allowable target error rate. The Accuracy test is designed to test the ability of the system to "capture, record, store, consolidate and report" specific selections and absences of a selection. The required accuracy is defined as an error rate. This rate is the maximum number of errors allowed while processing a specified volume of data.

For paper-based voting systems the ballot positions on a paper ballot must be scanned to detect selections for individual candidates and contests and the conversion of those selections detected on the paper ballot converted into digital data.

Summary Findings

The accuracy requirements for the ICP, ICP2, and ICC units were met by the execution of the standard accuracy test utilizing hand-marked ballots of each ballot length supported by the system, and ballots produced by the ICX BMD, to achieve an accuracy rate greater than 1,549,703 correct ballot positions.

Test results from the D-Suite 5.5-B EAC test campaign for the ICX BMD, ICX DRE, ICE, and the ICX DRE with VVPAT were reused to satisfy requirements for this test campaign.

3.1.5.4 System Integration

System Integration is a system level test for the integrated operation of both hardware and software. System Integration evaluates the compatibility of the voting system software components or subsystems with one another, and with other components of the voting system environment. This compatibility was determined through functional tests integrating the voting system software with the remainder of the system. During test performance, the system was configured exactly as it would for normal field use. This included connecting all supporting equipment and peripherals including ballot boxes, voting booths (regular and accessible), and any physical security equipment such as locks and ties.

Summary Findings

During System Integration testing, three General Elections and three Primary Elections were successfully exercised on the voting system, as described below:

Three general elections with the following breakdowns:

- General Election GEN-01: A basic election held in 4 precincts, one of which is a split precinct. This election contains 19 contests compiled into 4 ballot styles. 5 of the contests are in all 4 ballot styles. The other 15 contests are split between at least 2 of the precincts with a maximum of 4 different contest spread across the 4 precincts.
- General Election GEN-02: A basic election held in 3 precincts. This election contains 15 contests compiled into 3 ballot styles. 10 of the contests are in all 3 ballot styles with the other five split across the 3 precincts.
- General Election GEN-03: A basic election held in 2 precincts. This election contains 8 contests and compiled into 2 ballot styles. 4 of the contests are in both ballot styles. The other 4 contests are split between the two precincts. This election is designed to functionally test the handling of multiple ballot styles, support for at least three languages including a character-based language, support for common voting variations, and audio support for at least three languages and an ADA binary input device.

Three primary elections with the following breakdowns:

- Primary Election PRIM-01: Open Primary Election in two precincts. This election contained thirty contests compiled into five ballot styles. Each ballot style contains 6 contests.
- Primary Election PRIM-02: Open Primary Election held in two precincts. This election contained thirteen contests compiled into three ballot styles. One contest is in all three ballot styles; all other contests are independent.
- Primary Election PRIM-03: A basic election held in 2 precincts. This election contains 10 contests and is compiled into 2 ballot styles. 2 of the contests are in both ballot styles. The other 8 contests are split between the two parties' ballots. This Primary Election is designed to functionally test the handling of multiple ballot styles, support for at least three languages including a character-based language, support for common voting variations, and audio support for at least three languages and an ADA binary input device.

The D-Suite 5.5-C System successfully passed the System Integration Test. During execution of the test procedure, it was verified that the D-Suite 5.5-C System successfully completed the system level integration tests with all actual results obtained during test execution matching the expected results.

3.1.6 Hardware Testing

The ICX BMD, ICX DRE, ICP, ICE, the ICX DRE with Report Printer, and the ICX DRE with VVPAT hardware testing were re-used from the previous Democracy Suite 5.5-B campaign and 5.5 EAC campaign. For this campaign, hardware testing consisting of the Temperature-Power Variation Testing was performed on the Canon DR-G2140 scanner only.

Pro V&V utilized third party testing during the performance of the hardware testing. Testing was performed at the NTS Longmont facility located in Longmont, Colorado. During test performance, Pro V&V qualified staff executed all testing.

Summary Findings

Based on the testing performed and the results obtained, as documented in NTS Test Report TR-PR114050, Revision 0, the DR-G2140 successfully completed the testing with no issues noted.

3.2 Anomalies and Resolutions

When a result is encountered during test performance that deviates from what is standard or expected, a root cause analysis is performed. Pro V&V considers it an anomaly if no root cause can be determined. In instances in which a root cause is established, the results are then considered deficiencies.

Summary Findings

There were no anomalies encountered during this test campaign.

3.3 Deficiencies and Resolutions

Any violation of the specified requirement or a result encountered during test performance that deviates from what is standard or expected in which a root cause is established was considered to be a deficiency. Any deficiencies encountered were logged throughout the test campaign into the Pro V&V tracking system (Mantis) for disposition and resolution. In each instance, if applicable, the resolutions were verified to be resolved through all required means of testing (regression testing, source code review, and TDP update) as needed.

There were no deficiencies noted during this test campaign.

4.0 **RECOMMENDATION FOR CERTIFICATION**

The D-Suite 5.5-C Voting System, as presented for testing, successfully met the requirements set forth for voting systems in the U.S. Election Assistance Commission (EAC) 2005 Voluntary Voting System Guidelines (VVSG), Version 1.0. Additionally, Pro V&V, Inc. has determined that the D-Suite 5.5-C functioned as a complete system during System Integration Testing. Based on the test findings, Pro V&V recommends the EAC grant the D-Suite 5.5-C System, as identified in Tables 4-1 through 4-29, certification to the EAC 2005 VVSG.

Coffeenance	Version	Filmone	Configu	iration
Software	Software Version Filename		Standard	Express
EMS Election Event Designer (EED)	5.5.40.2	setup.exe: EED_FED_CERT_Setup_x64.msi	Х	Х
EMS Results Tally and Reporting (RTR)	5.5.40.2	setup.exe: RTR_FED_CERT_Setup_x64.msi	Х	Х
EMS Application Server	5.5.40.2	setup.exe: APPS_FED_CERT_Setup_x64.ms i	Х	х
EMS File System Service (FSS)	5.5.40.2	setup.exe: FSSSetup.msi	Х	Х
EMS Audio Studio (AS)	5.5.40.2	setup.exe: EMSAudioStudioSetup.msi	Х	Х
EMS Data Center Manager (DCM)	5.5.40.2	DemocracySuiteEMS_DCM.exe	Х	Х
EMS Election Data Translator (EDT)	5.5.40.2	setup.exe: EDTSetup_x86.msi EDTSetup_x64.msi	Х	Х
ImageCast Voter Activation (ICVA)	5.5.40.2	setup.exe: ICVASetup.msi	Х	Х
EMS Adjudication (Adj.)	5.5.40.1	DVS ImageCast Adjudication Client Setup.msi	Х	Х
EMS Adjudication Service	5.5.40.1	DVS Adjudication Services Setup.msi	Х	Х
Smart Card Helper Service	5.5.40.2	setup.exe: SmartCardServiceSetup.msi	Х	Х

Table 4-1. Democracy Suite 5.5-C EMS Software Component Descriptions

Firmware/Software	Version	Filename
Election Firmware	5.5.41.3	cf2xx.sig
Firmware Updater	5.5.41.3	firmUp.enc
Firmware Extractor	5.5.41.3	FirmwareExtract.enc
Kernel (uClinux)	5.5.41.3	image.bin.gz
Boot Loader (COLILO)	20040221	colilo.bin
Asymmetric Key Generator	5.5.41.3	Keygen.enc
Asymmetric Key Exchange Utility	5.5.41.3	KeyExchange.enc
Firmware Extractor (Uses Technician Key)	5.5.41.3	TechExtract.enc

 Table 4-2. Democracy Suite 5.5-C ImageCast Precinct Software Component Descriptions

Table 4-3. Democracy	Suite 5.5-C ImageCast	Central Software Component	Descriptions

Firmware/Software	Version	Filename
ImageCast Central Application	5.5.41.0002	ICCSetup.exe

Table 4-4. Democracy Suite 5.5-C ImageCast X Software Component Descriptions

Firmware/Software	Version	Filename
ICX Application	5.5.15.2	ICX.apk

Table 4-5. Democracy Suite 5.5-C ImageCast Precinct 2 Software Component Descriptions

Firmware/Software	Version	Filename
ICP2 Application	5.5.2.1	dvs-release-image-icp2-5.5.2.1.vhd.7z
ICP2 Application (for units with 2 GB RAM)	5.5.2.1	dvs-release-image-icp2-2G-5.5. 2.1.vhd.7z
ICP2 Update Card	5.5.2.1	icp2-update-5.5. 2.1

Table 4-6. Democracy Suite 5.5-C ImageCast Evolution Software Component Descriptions

Firmware/Software	Version	Filename
Voting Machine	5.5.6.5	GApplication-5.5.6.5.vhd.7z
Election Application	5.5.6.5	dvs
Linux Kernel	2.6.30.9-dvs-36	uImage
Linux Device File	1.6	mpc8347dvs.dtb
Root File System	5.0.31	rfs
Ram Disk	1.0.2	initrd.img
Motherboard FPGA	1.1.5	ice2_mc_p1.bit

Firmware/Software	Version	Filename
Scanner Board FPGA	1.1.2	ice2_scb_p2.bit
Logger Controller	2.0.2	logger.bin
Power Controller	3.0.5	power.bin
Boot Loader	1.3.4.63	u-boot.bin
Integrated Printer	4.1.6	integratedPrinter.hex, printerFont.hex
Boot Startup Logo	6.0.0	logo_platform.bmp
Linux Startup Logo	6.0.0	logo_os.bmp
Application Startup Logo	6.0.0	application_startup_logo.bmp
Application Verification Logo	6.0.0	logo_application_verification.bmp
Ram Disk Verification Logo	6.0.0	logo_ramdisk_verification.bmp
Linux Tree Verification Logo	6.0.0	logo_os_tree_verification.bmp
Linux Verification Logo	6.0.0	logo_os_verification.bmp
RFS Verification Logo	6.0.0	logo_rfs_verification.bmp

 Table 4-6. Democracy Suite 5.5-C ImageCast Evolution Software Component Descriptions

 (continued)

Table 4-7. Democracy Suite 5.5-C EMS Client/Server Software Component Descriptions

Firmware/Software	Vansian	Version Eileneme Conf		guration	
Firmware/Soltware	Version	Filename	Standard	Express	
Microsoft Windows Server	2012 R2 Standard	Physical Media from Microsoft	Х		
Microsoft Windows	10 Professional	Physical Media from Microsoft	Х	Х	
.NET Framework	3.5	Physical Media from Microsoft	Х	Х	
Microsoft Visual J#	2.0	vjredist64.exe vjredist.exe	Х	Х	
Microsoft Visual C++ 2013 Redistributable	2013	vcredist_x64.exe vcredist_x86.exe	Х	X	
Microsoft Visual C++ 2015 Redistributable	2015	vc_redist_x66.exe vc_redist.x86.exe	Х	Х	
Java Runtime Environment	7u80	jre-7u80-windows-x64.exe jre-7u80-windows-i586.exe	Х	Х	
Java Runtime Environment	8u144	jre-8u144-windows-x64.exe jre-8u144-windows-i586.exe	Х	Х	
Microsoft SQL Server 2016 Standard	2016 Standard	Physical Media from Microsoft	Х		
Microsoft SQL Server 2016 Service Pack 2	2016 SP2	SQLServer2016SP2- KB4052908-x64-ENU.exe	Х		

Firmware/Software	re Version Filename		Configuration	
Firmware/Soltware	version	Fliename	Standard	Express
Microsoft SQL Server 2016 SP1 Express	2016 SP1	SQLEXPRADV_x64_ENU.exe		Х
Cepstral Voices	6.2.3.801	English: Allison for Windows: Cepstral_Allison_windows_6.2. 3.801.exe David for Windows: Cepstral_David_windows_6.2.3 .801.exe Spanish: Alejandra for Windows: Cepstral_Alejandra_windows_6 .2.3.801.exe Miguel for Windows: Cepstral_Miguel_windows_6.2. 3.801.exe	Х	Х
Arial Narrow Fonts	2.37a	ARIALN.TTF ARIALNB.TTF ARIALNBI.TTF ARIALNI.TTF	Х	Х
Maxim iButton Driver	4.05	install_1_wire_drivers_x86_v4 05.msi install_1_wire_drivers_x64_v4 05.msi	Х	Х
Adobe Reader DC	AcrobatDC	AcroRdrDC1501020060_en_U S.exe	Х	Х
Microsoft Access Database Engine	2010	AccessDatabaseEngine.exe AccessDatabaseEngine_x64.ex e	Х	Х
Open XML SDK 2.0 for Microsoft Office	2.0	OpenXMLSDKv2.msi	Х	Х

Table 4-7. Democracy Suite 5.5-C EMS Client/Server Software Component Descriptions (continued)

Table 4-8. Democracy Suite 5.5-C EMS Software Platform Unmodified COTS Component Descriptions

Firmware/Software	Version	Filename
Infragistics NetAdvantage	2011	NetAdvantage_WinForms_20111.msi
Win Forms 2011.1	Vol.1	NetAdvantage_wini offits_20111.inst
Infragistics NetAdvantage	2012	NetAdvantage_WPF_20121.msi
WPF 2012.1	Vol.1	NetAdvalitage_wff_20121.illsi
TX Text Control Library	16.0	TXText Control.NET for Windows Forms
for .NET	10.0	16.0.exe
SOX	14.3.1	sox.exe, libgomp-1.dll, pthreadgc2.dll, zlib1.dll
NLog	1.0.0.505	NLog.dll

Firmware/Software	Version	Filename
iTextSharp	5.0.5	itextsharp.dll
OpenSSL	1.0.2k & 2.0.14 FIPS	openssl.exe, libeay32.dll, ssleay32.dll
SQLite	1.0.103.0	System.Data.SQLite.DLL (32-bit and 64-bit)
Lame	3.99.4	lame.exe
Speex	1.0.4	speexdec.exe and speexenc.exe
Ghostscript	9.04	gsdll32.dll (32-bit and 64-bit)
One Wire API for .NET	4.0.2.0	OneWireAPI.NET.dll
Avalon-framework-cvs- 20020806	20020806	avalon-framework-cvs-20020806.jar
Batik	0.20-5	batik.jar
Fop	0.20-5	fop.jar
Microsoft Visual J# 2.0 Redistributable Package- Second Edition(x64)	2.0	vjc.dll , vjsjbc.dll, vjslibcw.dll, vjsnativ.dll , vjssupuilib.dll , vjsvwaux.dll
Entity framework	6.1.3	EntityFramework.dll
Spreadsheetlight	3.4.3	SpreadsheetLight.dll, SpreadsheetLight.xml
Open XML SDK 2.0 For Microsoft Office	2.0.5022.0	DocumentFormat.OpenXml.dll, DocumentFormat.OpenXml.xml

 Table 4-8. Democracy Suite 5.5-C EMS Software Platform Unmodified COTS Component Descriptions (continued)

 Table 4-9. Democracy Suite 5.5-C ImageCast Precinct Unmodified COTS Component Descriptions

Firmware/Software	Version	Filename
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz
Zlib	1.2.3	Zlib-1.2.3.tar.gz

Table 4-10. Democracy Suite 5.5-C ImageCast Precinct 2 Unmodified COTS Component Descriptions

Firmware/Software	Version	Filename
acl	2.2.52	acl-2.2.52.src.tar.gz
attr	2.4.47	attr-2.4.47.src.tar.gz
avahi	0.6.32	avahi-0.6.32.tar.gz
bash	4.3.30	bash-4.3.30.tar.gz
bash-completion	2.4	bash-completion-2.4.tar.xz

Firmware/Software	Version	Filename
busybox	1.24.1	busybox-1.24.1.tar.bz2
bzip2	1.0.6	bzip2-1.0.6.tar.gz
coreutils	8.25	coreutils-8.25.tar.xz
cryptodev-linux	1.8	cryptodev-linux-1.8.tar.gz
cups	2.1.4	cups-2.1.4-source.tar.gz
db	6.0.35	db-6.0.35.tar.gz
dbus	1.10.10	dbus-1.10.10.tar.gz
dbus-glib	0.106	dbus-glib-0.106.tar.gz
dbus-test	1.10.10	dbus-1.10.10.tar.gz
depmodwrapper-cross	1	morty.tar.gz
e2fsprogs	1.43	e2fsprogs.git.tar.gz
expat	2.2.0	expat-2.2.0.tar.bz2
fontconfig	2.12.1	fontconfig-2.12.1.tar.gz
freetype	2.6.5	freetype-2.6.5.tar.bz2
gawk	4.1.3	gawk-4.1.3.tar.gz
gcc-runtime	6.2.0	gcc-6.2.0.tar.bz2
gettext	0.19.8.1	gettext-0.19.8.1.tar.gz
glib-2.0	2.48.2	glib-2.48.2.tar.xz
glibc	2.24	git2_sourceware.org.git.glibc.git.tar.gz
glibc-initial	2.24	git2_sourceware.org.git.glibc.git.tar.gz
glibc-locale	2.24	git2_sourceware.org.git.glibc.git.tar.gz
gmp	6.1.1	gmp-6.1.1.tar.bz2
gnutls	3.5.3	gnutls-3.5.3.tar.xz
gobject-introspection	1.48.0	gobject-introspection-1.48.0.tar.xz
grep	2.25	grep-2.25.tar.xz
icu	57.1	icu4c-57_1-src.tgz
imx-gpu-viv	6.2.2.p0-aarch32	imx-gpu-viv-6.2.2.p0-aarch32.bin
kbd	2.0.3	kbd-2.0.3.tar.xz
kernel-module-imx-gpu-viv	6.2.2.p0	kernel-module-imx-gpu-viv- 6.2.2.p0.tar.gz
kmod	23+gitAUTOINC +65a885df5f	git2_git.kernel.org.pub.scm.utils.kernel. kmod.kmod.git.tar.gz

Table 4-10. Democracy Suite 5.5-C ImageCast Precinct 2 Unmodified COTS Component Descriptions (continued)

Firmware/Software	Version	Filename
libcap	2.25	libcap-2.25.tar.xz
libcgroup	0.41	libcgroup-0.41.tar.bz2
libcheck	0.10.0	check-0.10.0.tar.gz
libdaemon	0.14	libdaemon-0.14.tar.gz
libdrm	2.4.70	libdrm-2.4.70.tar.bz2
libevdev	1.5.2	libevdev-1.5.2.tar.xz
libffi	3.2.1	libffi-3.2.1.tar.gz
libgcc	6.2.0	libgcc-5-dev_5.4.0- 6ubuntu1~16.04.10_amd64.deb
libgcc-initial	6.2.0	libgcc-5-dev_5.4.0- 6ubuntu1~16.04.10_amd64.deb
libidn	1.33	libidn-1.33.tar.gz
libinput	1.8.4	libinput-1.8.4.tar.xz
libjpeg-turbo	1.5.0	libjpeg-turbo-1.5.0.tar.gz
libnss-mdns	0.1	nss-mdns-0.10.tar.gz
libpcap	1.7.4	libpcap-1.7.4.tar.gz
libpciaccess	0.13.4	libpciaccess-0.13.4.tar.bz2
libpcre	8.39	libpcre32-3_2%3a8.38-3.1_amd64.deb
libpng	1.6.24	libpng-1.6.24.tar.xz
libpthread-stubs	0.3	libpthread-stubs-0.3.tar.bz2
libtool-cross	2.4.6	libtool-2.4.6.tar.gz
libusb1	1.0.20	libusb-1.0.20.tar.bz2
libusb-compat	0.1.5	libusb-compat-0.1.5.tar.bz2
libxkbcommon	0.6.1	libxkbcommon-0.6.1.tar.xz
libxml2	2.9.4	libxml2-2.9.4.tar.gz
linux-libc-headers	4.9	linux-4.9.tar.xz
log4cplus	1.2.0	log4cplus-1.2.0.tar.gz
m4	1.4.17	m4-1.4.17.tar.gz
mesa	12.0.1	mesa-12.0.1.tar.xz
mtdev	1.1.5	mtdev-1.1.5.tar.bz2
nettle	3.2	nettle-3.2.tar.gz
openssl	1.0.2k	openssl-1.0.2k.tar.gz

Table 4-10. Democracy Suite 5.5-C ImageCast Precinct 2 Unmodified COTS Component Descriptions (continued)

Firmware/Software	Version	Filename
openssl-fips	2.0.10	openssl-fips-2.0.10.tar.gz
opkg-utils	0.3.2+gitAUTOI NC+3ffe ce9bf1	opkg-0.3.3.tar.gz
pkgconfig	0.29.1+gitAUTO INC+87152c05b e	git2_anongit.freedesktop.org.pkg- config.tar.gz
ppp	2.4.7	ppp-2.4.7.tar.gz
procps	3.3.12	procps-ng-3.3.12.tar.xz
qtbase	5.9.6+gitAUTOI NC+f4c2fcc052	qtbase- 5.9.6+gitAUTOINC+9c50112304.tar.gz
qtdeclarative	5.9.6+gitAUTOI NC+dfb e918537	qtdeclarative- 5.9.6+gitAUTOINC+283a900c4e.tar.gz
qtgraphicaleffects	5.9.6+gitAUTOIN C+3d317f1bb0	qtgraphicaleffects- 5.9.6+gitAUTOINC+f61dcaa5e5.tar.gz
qtquickcontrols2	5.9.6+gitAUTOI NC+c51 eea8870	qtquickcontrols2- 5.9.6+gitAUTOINC+c48b314ede.tar.gz
qtquickcontrols	5.9.6+gitAUTOI NC+f050a32a43	qtquickcontrols- 5.9.6+gitAUTOINC+ca6bba7163.tar.gz
qtsvg	5.9.6+gitAUTOI NC+dec74295e8	qtsvg- 5.9.6+gitAUTOINC+7a28db8f5b.tar.gz
qtxmlpatterns	5.9.6+gitAUTOI NC+c7c5681004	qtxmlpatterns- 5.9.6+gitAUTOINC+4dcae15a5a.tar.gz
quazip	0.7.3	quazip-0.7.3.tar.gz
readline	6.3	readline-6.3.tar.gz
run-postinsts	1	morty.tar.gz
sed	4.2.2	sed-4.2.2.tar.gz
shadow	4.2.1	shadow-4.2.1.tar.xz
shadow-securetty	4.2.1	shadow-4.2.1.tar.xz
sqlite3	3.14.1	sqlite-autoconf-3140100.tar.gz
systemd	230+gitAUTOIN C+3a74d4fc90	git2_github.com.systemd.systemd.git.ta r.gz
tcl	8.6.6	tcl8.6.6-src.tar.gz
tslib	1.1	tslib-1.1.tar.xz
tzdata	2017a	tzdata2017a.tar.gz
usb-modeswitch	2.2.0	usb-modeswitch-2.2.0.tar.bz2
usb-modeswitch- data	20140529	usb-modeswitch-data-20140529.tar.bz2
util-linux	2.28.1	util-linux-2.28.1.tar.xz
util-macros	1.19.0	util-macros-1.19.0.tar.gz

Table 4-10. Democracy Suite 5.5-C ImageCast Precinct 2 Unmodified COTS Component Descriptions (continued)

Firmware/Software	Version	Filename
XZ	5.2.2	xz-5.2.2.tar.gz
zbar	0.1	zbar-0.10.tar.bz2
zlib	1.2.8	zlib-1.2.8.tar.xz
flac	1.3.1	flac-1.3.1.tar.xz
gst-plugins-base	1.10.4	gst-plugins-base-1.10.4.tar.xz
gst-plugins-good	1.10.4	gst-plugins-good-1.10.4.tar.xz
gstreamer	1.10.4	gstreamer-1.10.4.tar.xz
harfbuzz	1.3.0	harfbuzz-1.3.0.tar.bz2
libgudev	230	libgudev-230.tar.xz
libical	2.0.0	libical-2.0.0.tar.gz
libogg	1.3.2	libogg-1.3.2.tar.xz
libsamplerate	0.1.8	libsamplerate-0.1.8.tar.gz
libsndfile	1.0.27	libsndfile-1.0.27.tar.gz
libvorbis	1.3.5	libvorbis-1.3.5.tar.xz
speex	1.2rc2	speex-1.2rc2.tar.gz
speexdsp	1.2rc3	speexdsp-1.2rc3.tar.gz
taglib	1.9.1	taglib-1.9.1.tar.gz
qtmultimedia	5.9.6+gitAUTOI NC+52f5785cfa	qtmultimedia- 5.9.6+gitAUTOINC+52f5785cfa.tar.gz

 Table 4-10. Democracy Suite 5.5-C ImageCast Precinct 2 Unmodified COTS Component Descriptions (continued)

Table 4-11. Democracy Suite 5.5-C ImageCast Evolution Unmodified COTS Component Descriptions

Firmware/Software	Version	Filename
BusyBox	1.20.2	busybox-1.20.2.tar.bz2
e2fsprogs	1.42.4	e2fsprogs-1.42.4.tar.gz
Expat XML Parser	2.1.0	expat-2.1.0.tar.gz
fontconfig	2.9.0	fontconfig-2.9.0.tar.gz
Freetype	2.4.9	freetype-2.4.9.tar.bz2
I2C Tools for Linux	3.1.0	i2c-tools-3.1.0.tar.bz2
JPEG library	8d	jpegsrc.v8d.tar.gz
libogg	1.3.0	libogg-1.3.0.tar.gz
libPNG	1.5.10	libpng-1.5.10.tar.gz

Firmware/Software	Version	Filename
libusb	1.0.8	libusb-1.0.8.tar.bz2
libusb-compat	0.1.3	libusb-compat-0.1.3.tar.bz2
log4cplus	1.0.4.1	log4cplus-1.0.4.1.tar.bz2
openssl	1.0.2k	openssl-1.0.2k.tar.gz
openssl-fips	2.0.10	openssl-fips-2.0.10.tar.gz
PPP	2.4.5	ppp-2.4.5.tar.gz
quazip	0.5	quazip-0.5.tar.gz
Qt Everywhere Linux	4.7.3	qt-everywhere-opensource-src- 4.7.3.tar.gz
skell	1.19	skell-1.19.tar.gz
SoundTouch	1.6.0	soundtouch-1.6.0.tar.gz
speex	1.2rc1	speex-1.2rc1.tar.gz
SQLite	3.7.13	sqlite-autoconf-3071300.tar.gz
Sysfs Utilities	2.1.0	sysfsutils-2.1.0.tar.gz
TIFF library	4.0.1	tiff-4.0.1.tar.gz
timezone	2012b	tzcode2012b.tar.gz
USB ModeSwitch	1.2.4	usb-modeswitch-1.2.4.tar.bz2
zlib	1.2.7	zlib-1.2.7.tar.bz2

 Table 4-11. Democracy Suite 5.5-C ImageCast Evolution Unmodified COTS Component Descriptions (continued)

Table 4-12. Democracy Suite 5.5-C ImageCast X Unmodified COTS Component Descriptions

Firmware/Software	Version	Filename
		ARM: com.google.android.tts_3.11.12-
Google Text-to-Speech	3.11.12	210311121_minAPI19(armeabi-v7a)(nodpi).apk
Engine	5.11.12	x86: com.google.android.tts_3.11.12-
-		210311123_minAPI15(x86)(nodpi).apk
ICX Prime Android	5.1.1-	200420.5111172 year and reid $x^{9}6$ iso
5.1.1 Image	1.17.3	200430_5.1.1-1.17.3_user_android_x86.iso
ICX Classic Android 4.4.4 Image	0.0.98	byt_t_crv2_64-ota-BCX18-V0.0.98.zip

Table 4-13. Democracy Suite 5.5-C ImageCast Central Software Build Library Source Code (Unmodified COTS)

Firmware/Software	Version	Filename
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz

Table 4-14. Democracy Suite 5.5-C ImageCast Central Runtime Software Components (Unmodified COTS)

Firmware/Software	Version	Filename
1-Wire Driver (x86)	4.05	install_1_wire_drivers_x86_v405.msi
1-Wire Driver (x64)	4.05	install_1_wire_drivers_x64_v405.msi
Canon DR-G1130 TWAIN Driver	1.2 SP6	G1130_DRIT_V12SP6.exe
Canon DR-M160II TWAIN Driver	1.2 SP6	M160II_DRIT_V12SP6.exe
Visual C++ 2013 Redistributable (x86)	12.0.30501	vcredist_x86.exe
InoTec HiPro 821 TWAIN Driver	1.2.0.5	TwainSetup-ScamaxUSB3.exe
Canon DR-M260 TWAIN Driver	1.1 SP2	M260_DRIT_V11SP2.zip

Table 4-15. Democracy Suite 5.5-C ImageCast Precinct Modified COTS Software Component Descriptions

Firmware/Software	Version	Filename
uClinux	20070130	uClinux-dist-20070130.tar.gz
COLILO Bootloader	20040221	Colilo20040221.tar.gz

Table 4-16. Democracy Suite 5.5-C ImageCast Precinct 2 Modified COTS Software Component Descriptions

Firmware/Software	Version	Filename
Kernel	4.9.11	zImage
U-BOOT	2017.03	u-boot.bin

Table 4-17. Democracy Suite 5.5-C ImageCast Evolution Modified COTS Software Component Descriptions

Firmware/Software	Version	Filename
Kernel	2.6.30	uImage
U-BOOT	1.3.4	u-boot.bin

Table 4-18. Democracy Suite 5.5-C ImageCast X Modified COTS Software Component Descriptions

Firmware/Software	Version	Filename
Zxing Barcode Scanner	4.7.5	BS-4.7.5.zip
SoundTouch	1.9.2	Soundtouch-1.9.2.tar.gz

Table 4-19. Democracy Suite 5.5-C EMS Software Build Environment Component Descriptions

Firmware/Software	Version	Filename
Windows 10 Professional	10 Professional	Physical Media from Microsoft
.NET Framework 3.5	3.5	Physical Media from Microsoft
Internet Information Server (IIS)	10.0	Physical Media from Microsoft
7-Zip	9.20 (64 Bit)	7z920-x64.msi
Visual Studio 2015 Professional with Update 3	2015 Update 3	en_visual_studio_professional_2015_wi th_update_3_x86_x64_web_installer_8 922978.exe
.NetDiscUtils	0.10	DiscUtilsBin-0.10.zip
Infragistics NetAdvantage Win Forms 2011.1	2011.1	NetAdvantage_WinForms_20111.msi
Infragistics Net Advantage – WPF 2012.1	2012.1	NetAdvantage_WPF_20121.msi
TX Text Control 16.0.NET	16	TX Text Control.NET for Windows Forms 16.0.exe
Speex	1.0.4	speex_win32_1.0.4_setup.exe
Microsoft Visual J#	2.0	vjredist64.exe
iTextSharp	5.0.5	itextsharp-5.0.5-dll.zip
Ghostscript	9.0.4	gs904w32.exe, gs904w64.exe
Nlog	1.0.0.505	NLog-1.0-Refresh-bin.zip
OneWireAPI.NET	4.0	1-wiresdkver400_beta2.zip
Lame	3.99.4	lame3.99.4-20120130.zip
Sox	14.3.1	sox-14.3.1-win32.zip
Avalon Framework	20020806	avalon-framework-cvs-20020806.jar.zip
Fop	0.20-5	fop-0.20.5.jar
Batik	0.20-5	batik-1.5-fop-0.20-5.jar
SQLite	1.0.103.0	sqlite-netFx46-setup-bundle-x64-2015- 1.0.103.0.exe
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz

Firmware/Software	Version	Filename
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz
Strawberry Perl	5.24.1.1	strawberry-perl-5.24.1.1-64bit.msi
Patch	2.5.9-7	patch-2.5.9-7-bin.zip
ISOnewspaper	30.4	ISOnewspaper30v4_gr.icc.zip
Ogg Vorbis Encoder	2.88	oggenc2.88-1.3.5-generic.zip
Ogg Vorbis Encoder	1.10.1	oggdecV1.10.1.zip
Prism Mvvm	1.1.1	prism.mvvm.1.1.1.nupkg
Bitmiracle.libtiff.net	2.4.560	Bitmiracle.libtiff.net.2.4.560.nupkg
Prism	4.0.0	prism.4.0.0.nupkg
Prism.UnityExtensions	4.0.0	prism.unityextensions.4.0.0.nupkg
PDF Printing	2.9.5.2	PDFPrinting.zip
Entity Framework	6.1.3.net45	entityframework.6.1.3.nupkg
WiX	3.10	Wix310.exe
Spreadsheet Light	3.4.3	spreadsheetlight.3.4.3.nupkg
Open XML SDK 2.0 for Microsoft Office	2.0	OpenXMLSDKv2.msi
Adobe Reader DC	AcrobatDC	AcroRdrDC1501020060_en_US.exe
Arial Narrow Fonts	2.37a	ArialNarrowFonts.zip
SSH.NET	2016.1.0	SSH.NET-2016.1.0-bin.zip
SSMS	14.0.17119.0	SSMS-Setup-ENU.exe
TwainDSM	2.3.0	Twaindsm-2.3.0.win.bin

 Table 4-19. Democracy Suite 5.5-C EMS Software Build Environment Component Descriptions (continued)

Table 4-20. Democracy Suite 5.5-C ICC Software Build Environment Component Descriptions

Firmware/Software	Version	Filename
NASM Assembler	2.12.02	nasm-2.12.02-win32.zip
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz
CSC3-2010	N/A	CSC3-2010.crl
tss-ca-g2	N/A	tss-ca-g2.crl

Firmware/Software	Version	Filename
Microsoft Enterprise Library	5.0	Enterprise Library 5.0.msi
Microsoft Prism	4.0.0	Prism.4.0.0.nupkg
Microsoft Identity Foundation SDK	4.0	WindowsIdentityFoundation-SDK- 4.0.msi
Toggle Switch Control Library	1.1.1	ToggleSwitch 1.1.1.zip
Infragistics NetAdvantage Ultimate 2013.1	2013.1	NetAdvantage_20131_PlatformInst aller.zip
iTextSharp	5.5.1	itextsharp-all-5.5.1.zip
CLR Security	June 2010	clrsecurity_june10.zip
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz
Community MSI Extensions	1.4	msiext-1.4.zip
TreeViewEx	3.0.0.0	TreeViewEx.dll

Table 4-21. Democracy Suite 5.5-C Adjudication Software Build Environment Component Descriptions

Table 4-22. Democracy Suite 5.5-C ImageCast Precinct Election Firmware Compiler Descriptions

Firmware/Software	Version	Filename
g++ (GNU C++	gcc3.4.0-20040603	m68k-uclinux-tools-c++-gcc3.4.0-
compiler)	8	20040603.sh

Table 4-23. Democracy Suite 5.5-C ImageCast Precinct Firmware Build Environment Component Descriptions

Firmware/Software	Version	Filename
Ubuntu 16.04.1	16.04.1	ubuntu-16.04.1-desktop-i386.iso
Toolchain Installation Script	N/A	Toolchain.sh
m68k uClinux tools base gcc	3.4.0-20040603	m68k-uclinux-tools-base-gcc3.4.0- 20040603.sh
m68k uClinux tools c++ gcc	3.4.0-20040603	m68k-uclinux-tools-c++-gcc3.4.0- 20040603.sh
m68k uClinux tools gdb	20040603	m68k-uclinux-tools-gdb-20040603.sh
OpenSSL 1.0.2k	1.0.2k	openssl-1.0.2k.tar.gz
OpenSSL FIPS 2.0.10	2.0.10	openssl-fips-2.0.10.tar.gz

Firmware/Software	Version	Filename
Ubuntu	16.04 LTS	ubuntu-16.04.5-desktop-amd64.iso
Yocto	imx-morty	morty.tar.gz
asciidoc	8.6.9	asciidoc_8.6.9-3_all.deb
autoconf	2.69	autoconf_2.69-9_all.deb
automake	1.15	automake_1%3a1.15-4ubuntu1_all.deb
p7zip- full	9.20.1~dfsg.1	p7zip-full_9.20.1~dfsg.1-4.2_amd64.deb
avr-libc	1.8.0+Atmel3.5.0	avr-libc_1%3a1.8.0+Atmel3.5.0-1_all.deb
binutils-avr_	2.25+Atmel3.5.0	binutils-avr_2.25+Atmel3.5.0- 2_amd64.deb
python-dev	2.7.12	python-dev_2.7.12-1~16.04_amd64.deb
python3	3.5.1	python3-dev_3.5.1-3_amd64.deb
python3-pip	8.1.1	python3-pip_8.1.1-2ubuntu0.4_all.deb
python-pysqlite2	2.7.0	python-pysqlite2_2.7.0-1_amd64.deb
chrpath	0.16	chrpath_0.16-1_amd64.deb
socat	1.7.3.1	socat_1.7.3.1-1_amd64.deb
cvs	1.12.13	cvs_2%3a1.12.13+real- 15ubuntu0.1_amd64.deb
desktop-file-utils	0.22	desktop-file-utils_0.22- 1ubuntu5.2_amd64.deb
psutils	1.17.dfsg	psutils_1.17.dfsg-2_amd64.deb
docbook-utils	0.6.14	docbook-utils_0.6.14-3ubuntu1_all.deb
libsdl1.2-dev	1.2.15+dfsg1	libsdl1.2-dev_1.2.15+dfsg1-3_amd64.deb
help2man	1.47.3	help2man_1.47.3_amd64.deb
texi2html	1.82+dfsg1	texi2html_1.82+dfsg1-5_all.deb
libgl1-mesa-dev	18.0.5	libgl1-mesa-dev_18.0.5- 0ubuntu0~16.04.1_amd64.deb
libglu1-mesa-dev	9.0.0	libglu1-mesa-dev_9.0.0-2.1_amd64.deb
mercurial	3.7.3	mercurial_3.7.3-1ubuntu1_amd64.deb
g++-5	5.4.0	g++-5_5.4.0- 6ubuntu1~16.04.10_amd64.deb
gawk	4.1.3	gawk_1%3a4.1.3+dfsg-0.1_amd64.deb
lzop	1.03	lzop_1.03-3.2_amd64.deb
gcc	5.4.0	gcc-5_5.4.0- 6ubuntu1~16.04.10_amd64.deb

Table 4-24. Democracy Suite 5.5-C ImageCast Precinct 2 Firmware Build Environment Component Descriptions

Table 4-24. Democracy Suite 5.5-C ImageCast Precinct 2 Firmware Build Environment
Component Descriptions (continued)

Firmware/Software	Version	Filename
gcc-5-multilib	5.4.0	gcc-5-multilib_5.4.0-
gee-5-mattino	5.4.0	6ubuntu1~16.04.10_amd64.deb
gcc-avr	4.9.2+Atmel3.5.3	gcc-avr_1%3a4.9.2+Atmel3.5.0-
gee-avi	4.9.2+Auner5.5.5	1_amd64.deb
git	2.7.4	git_1%3a2.7.4-0ubuntu1.4_amd64.deb
zlib	1.2.8	zlib1g-dev_1%3a1.2.8.dfsg-
2110	1.2.0	2ubuntu4.1_amd64.deb
texinfo	6.1.0.dfsg.1	texinfo_6.1.0.dfsg.1-5_amd64.deb
groff	1.22.3	groff_1.22.3-7_amd64.deb

Table 4-25. Democracy Suite 5.5-C ImageCast Evolution Firmware Build Environment Component Descriptions

Firmware/Software	Version	Filename
Ubuntu	10.04 LTS	ubuntu-10.04.4-desktop-i386.iso
LTIB	10.1.1a	ltib-10-1-1a-sv.tar.gz
g++ (GNU C++ compiler)	gcc-4.5.38- eglibc-2.11.38	freescale-powerpc-linux-gnu-2011.03- 38.i686.rpm
autoconf	2.57	autoconf-2.57.tar.bz2
bison	2.3	bison-2.3.tar.bz2
ccache	2.4	ccache-2.4.tar.gz
cksum	19990607	cksum-19990607.tar.gz
cramfs	20081121	cramfs-20081121.tar.gz
distcc	2.18.3	distcc-2.18.3.tar.bz2
dtc	1.2.0	dtc-1.2.0.tar.gz
flex	2.5.33	flex-2.5.33.tar.gz
genext2fs	1.4.1	genext2fs-1.4.1.tar.gz
gen_init_cpio	2.6.25-rc7	gen_init_cpio-2.6.25-rc7.tar.gz
genromfs	0.5.1	genromfs-0.5.1.tar.gz
git	1.5.6.5	git-1.5.6.5.tar.gz
libtool	1.5	libtool-1.5.tar.gz
lkc	1.4	lkc-1.4.tar.gz
mkspooflinks	3.4	mkspooflinks-3.4.tar.gz
mtd-utils	20060302	mtd-utils-20060302.tar.bz2
mux_server	1.0	mux_server.c
pkg-config	0.21	pkg-config-0.21.tar.gz
sparse	0.4	sparse-0.4.tar.gz

Table 4-25. Democracy Suite 5.5-C ImageCast Evolution Firmware Build Environment Component Descriptions (continued)

Firmware/Software	Version	Filename
texinfo	4.8	texinfo-4.8.tar.bz2
tunctl	1.5	tunctl-1.5.tar.gz
u-boot-tools	1.1.6	u-boot-tools-1.1.6.tar.bz2
unifdef	1.0	unifdef-1.0.tar.gz
wget	1.9.1	wget-1.9.1.tar.gz
yaffs_utils	20060418	yaffs_utils-20060418.tar.gz
rpm	4.0.4	rpm-4.0.4.tar.gz

Table 4-26. Democracy Suite 5.5-C ImageCast X Firmware Build Environment Component Descriptions

Firmware/Software	Version	Filename
Ubuntu 14.04.4	14.04.4	ubuntu-14.04.4-desktop-amd64.iso

Table 4-27. D-Suite 5.5-C Configuration Files

Configuration File	Version	Filename
ICX Machine Configuration File (MCF)	5.5.15.1_20200306	MCF_5.5.15.1_20200306.mcf
ICP/ICC Device Configuration File (DCF)	5.5.41.3_20200507	DCF_5.5.41.3_20200507.dcf"
ICE Machine Behavior Settings	5.5.6.3_20200415	behaviorsettings_ICE_5.5.6.3_EAC_5. 5-C_20200415.mbs
ICP2 Machine Behavior Settings	5.5.2.1_20200415	behaviorsettings_ICP2_5.5.2.1_EAC_ 5.5-C_20200415.mbs"

Table 4-28. D-Suite 5.5-C Voting System Equipment

Component	Serial Number	
Proprietary Hardware		
ImageCast Precinct Optical Scanner PCOS-320C	AAFAJFM0061, AAFAJFN0030, AAFAJGI6764, AAFAJEL0352	
ImageCast Precinct Optical Scanner PCOS-320A	AANAGCP0347, AANAGCP0002	
ImageCast Precinct 2 Optical Scanner PCOS-330A	FAL18480494, FAL18480510	
ImageCast Evolution Optical Scanner PCOS-410A	AAFEBIK1847, AAFEBCN0012	
ICP Ballot Box BOX-330A	AAUCCFX0083, AAUCCGI0011	
ICE Ballot Box		
ICX Inline EMI Filter	[DVS-EMIFILTER-001] thru [DVS-EMIFILTER-003]	
ICP2 Ballot Box BOX-350A		

Component	Serial Number	
COTS Hardware		
ICX aValue 15" Tablet (SID- 15V)	0E14AF00014, B03G005400006, B033G00540008, 9E274118, 1D274118, Baytrail98D750C0, Baytrail12034DCC, Baytrail9A6550C8	
ICX aValue 21" Tablet (SID- 21V)	0E14AF00027, B03G005500019, 03G005500009, 0039BZ2D, 0039B209, Baytrail0039B22D, BaytrailF1B2587F, BaytrailF1B25983	
aValue 21" ICX DRE (Prime)	1707101522, 1707101789, 1707101730, 1707101887, 1707101710, 1707101725, 1707101731, 1708100916, 1708100876, 1708100915, 1707101845, 1707101778, 1717101720, 1707101845, 1707101722, 1707202552, 1711300282, 1707100089, 1707101795, 1707101793, 17101793	
SII Thermal Printer	1115271A, 1115273A, 115270A, 1115275A	
KFI VRP3 Thermal Printer (VVPAT)	KPR000000715, KPR0000078339, KPR0000078377, KRP000000711, KPR000000712, KPR170900010119, KPR0000078337, KPR0000078364, KPR170900008115, KPR0000078339, KPR170900008116, KPR170900010347, KPR170900009733, KPR170900010120, KPR170900010119, KPR170900010337, KPR170900010338, KPR170900010348	
Dell OptiPlex 7440 All In One	HVNRFB2, HVNQFB2, HVNPFB2	
Dell PowerEdge R630	4Z07T52	
Dell PowerEdge R640	JMP9CM2	
Canon imageFormula DR-G1130 Scanner	GF301092, GF304418	
Canon DR-M160II Scanner	GX333569, GX333573, GX324846, GX326272, GX319353	
Canon DR-M260 Scanner	HG306013, HG306012	
Canon DR-G2140	JF301032	
InoTec HiPro 821 Scanner	0078K28, 0080K28	
Dell Precision T3420 PC	HS0VFB2, HS0TFB2, HS0RFB2, HS0SFB2, 4TB3MN2, F575HH2	
HP LaserJet Pro Printer M402dn	PHBQF20342, PHBQF20345, PHBQC12619, PHBQC19613, PHBQC12519, PHBQD18790, PHBQC12616, PHBQG09329	
HP LaserJet Pro Printer M402dne	PHB5D00782, PHB5D04714, PHB5F04770, PHB5B18304, PHB5D04713	
HP LaserJet Pro Printer M501dn	PHBTQ00049	
Dell OptiPlex 9030 All-In-One	CF73S52	
Dell Ultrasharp 24" Monitor U2414H	1PVZ152, 62VZ152	

Table 4-28. D-Suite 5.5-C Voting System Equipment (continued)

Table 4-28. D-Suite 5.5-C Voting System Equipment (continued)

Component	Serial Number
Dell OptiPlex 3050 All-In-One	19YWWK2
Smart Card Reader ACR39	RR374-010362

Table 4-29. D-Suite 5.5-C Voting System Support Equipment

Component	Serial Number
Dell Monitor KM632	FYNTY12, CKX6Y12, CN-0524N3-72461-59H-6U5U
Dell Monitor P2414Hb	CN-0524N3-74261-5AH-2DNU, CN-0524N3-74261- 5AH-2DAU
Dell DVD Multi Recorder GP60NB60	[DVS-Dell-001]
Dell Latitude E7450 Laptop	30GFH72, 369FH72
Dell Latitude e3480 Laptop	1VD3NJ2
Maxim iButton Programmer DS9490R# with DS1402	[DVS-Maxim-001] thru [DVS-Maxim-006]
APC Smart-UPS SMT1500	3\$1536X06436, 3\$1536X06475, 3\$1536X06461, 3\$1536X06485, 3\$1536X06484, 3\$1536X06322, 3\$1536X07467, 3\$1536X06485, 3\$1536X06272, 3\$1536X06201, 3\$1536X07305, 3\$1504X00395, 3\$1504X00396, 351716X02289, W51530180004, 3\$171X06059
Dell X1008 Network Switch	4R8XX42, 26SXX42
Dell X1018 Network Switch	6TN7Y42, 63SXX42
Enabling Devices Sip and Puff	[DVS-enabling devices-001] - [DVS-enabling devices- 002]
Cyber Acoustics Headphones ACM-70	[DVS-cyber acoustics-001] - [DVS-cyber acoustics- 005]
4-Way Joystick Controller S26	PME QC 1550 12, [DVS-JOY-001], [DVS-JOY-002]
Enablemart # 88906 Rocker (Paddle) Switch	[DVS-paddle-001]
Dell PowerConnect 2808 Network Switch	3S2P0Z1
IOGEAR SDHC/microSDHC 0U51USC410 Card Reader	8632, 8633
Lexar USB 3.0 Dual-Slot Reader	24020845007435
Hoodman Steel USB 3.0 UDMA Reader 102015	[DVS-hoodman-001]
ATI Handset	98862010101-035, 98862010103-075, 00659010100- 046, 98862010100-232, 093015-1-1, 00659010100-035
ATI-USB Handset	02440010100-011, [DVS-ATIUSB-001], [DVS- ATIUSB-002], B104326-1-4-040, B104326-1-4-035
ACS PC-Linked Smart Card Reader ACR39U	RR374-006272, RR374-010356, RR374-010365

Component	Serial Number
Lexar Professional CF Card Reader	24050361400108, 24050361401994, 24050361401991,
Workflow CFR1	24050361401990
CORCOM Filter P/N#: 15EMC1	[DVS-CorcomEMIFilter-001]
Delta Filter P/N#: 16PDCG5C	[DVS-DeltaEMIFILTER-001]
Kingston Card Reader FCR-HS4	08738174208132

Table 4-29. D-Suite 5.5-C Voting System Support Equipment (continued)

ATTACHMENT A

NTS Test Report TRPR114050, Revision 0